



Ergonomic 340.278 DG

Operating instructions

Before transporting and using the machine,
please read the instructions thoroughly!

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.03/ May 2016
rev. 1

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

^{1) 2)} We:

BOMAR, spol. s r.o.

Těžební 1236/1

627 00 Brno, Czech Republic

Id. No: 48908827

declare herewith

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government.

This statement applies exclusively to the machine device in conditions in which it was brought to the market. It does not apply to parts subsequently added by the end user or to modifications performed subsequently by the end user.

In the event of any device modification not approved by us this declaration shall lose its validity

Name: Band Saw

Type : Ergonomic 340.275 DG

Serial number:

Manufacturer BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno

Product data

Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics

Description: Stand, table, cutting unit with the saw band and drive, clamping device, cooling system, el. switch board with control panel.

Pneumatic NO ☒ YES ☐ Hydraulic NO ☒ YES ☐ Control system NO ☒ YES ☐

Technical data:

Cutting rate	20-120 m.min ⁻¹
Cutting angle	-45° - to -60°
Total dimensions in mm (l×w×h)	1960x1570x1770 mm
Supply voltage	400 V TN-C-S, 400 V TN-C, 230 V TN-C
Total power requirement	1,7 kW
Weight	372 kg

Documentation:

Technical documentation for this machine device was elaborated in compliance with Government regulation no. 176/2008, Annex 7, part A.

The device meets relevant requirements of the given directives:

2006/42/EC

2004/108/EC

The applied harmonized standards, National standards and technical specifications:

ČSN EN ISO 12100:2011

ČSN EN 13898+A1:2009

ČSN EN ISO 13857:2008

ČSN EN 60204 -1 ed.2+A1:2009

ČSN EN 55011 ed.3+A1:2011

ČSN EN 61000-6-2 ed.3:2006

ČSN EN 61000-6-4 ed.2+A1:2011

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended.

The declaration of conformity was carried out in the cooperation with the ³⁾ TÜV SÜD Czech s.r.o. Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002.

The inspection certificate no **07.801.283**

was issued

Brno, 31.08..2015

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827



Alfred Pichlmann, Managing Director

Point of issue, datum

Name and function of the responsible subject, signature

1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)

2) Person authorized to complete the technical documentation

3) The authorized or accredited body co-operating on the conformity judging

!

If the equipment is installed without safety equipment offered by BOMAR, spol. s ro or its agents and used by the customer (or buyer) then EC declaration loses validity.

EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.

All machine elements and components that were built into the device by BOMAR, spol. s ro have been declared "identical" to a safety device, as offered by BOMAR, spol. s ro or its agents.

Content

1. BEZPEČNOSTNÍ POKYNY / SAFETY NOTES / SICHERHEITSHINWEISE 11

1.1. Machine determination.....	13
1.2. Protective clothing and personal safety.....	13
1.3. Safety notes for machine operator.....	15
1.4. Safety notes for the servicing and repairs.....	17
1.4.1. Safety notes for the servicing and repairs on hydraulic unit.....	17
1.5. Safety notes for the cooling.....	17
1.5.1. Instructions for first aid.....	17
1.6. Safety machine accessories.....	19
1.6.1. Total Stop.....	19
1.6.2. Arm cover.....	19
1.6.3. Saw band covers.....	20
1.6.4. Saw band stretching and rupture inspection.....	21
1.7. Umístění štítku stroje / Maschinenschild position / Position of the machine label.....	22
1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	23

2. DOKUMENTACE STROJE / MACHINE DOCUMENTATION / DOKUMENTATION DER MASCHINE..... 25

2.1. Technická data / Technische Daten / Technical data.....	27
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram.....	28
2.3. Popis / Beschreibung / Description.....	30
2.4. Transportation and stocking.....	32
2.4.1. Conditions for transportation and stocking.....	32
2.4.2. Transport and stocking preparations.....	32
2.4.3. Transport and stocking.....	32
2.4.4. Transportní schéma / Transport schema / Transport diagram.....	33
2.5. Activation.....	34
2.5.1. Machine working conditions.....	34
2.6. Band saw unpacking and assembling.....	34
2.6.1. Installation of the length stop for the material length setting.....	34
2.6.2. Attachment of the cooling liquid tub.....	36
2.6.3. Assembly of the hand wheel.....	36
2.6.4. Machine installing and leveling.....	38
2.6.5. Machine disposal after lifetime.....	38
2.6.6. Kotevní plan / Verankerungsplan / Grounding plan.....	39
2.7. Electrical connection.....	40
2.7.1. Check the direction of the saw band.....	40
2.7.2. Inspection of the connection to the electrical network.....	41
2.8. Filling of the cooling system.....	41
2.9. Machine functions check.....	41
2.10. Saw band.....	42
2.10.1. Saw band size.....	42
2.10.2. Selection of the saw band tooth system.....	42
2.10.3. Saw band running-in.....	42
2.11. Table for teeth selection.....	44

3. OVLÁDÁNÍ STROJE / MACHINE CONTROL / BEDIENUNG DER MASCHINE 45

3.1. Starting the band saw and switching on the safety circuits.....	47
3.2. Control elements.....	48
3.3. Machine control.....	50
3.3.1. Cutting.....	50
3.3.2. Setting of the material length.....	52
3.3.3. Setting of the cutting angle.....	53
3.3.4. Setting of the optimal span of the guiding cubes.....	56
3.3.5. Cutting speed adjustment.....	56

3.3.6.	Speed adjustment of the arm lowering.....	56
3.3.7.	Setting the type of cooling	58
3.4.	Material insertion	59
3.4.1.	Selecting means of manipulation.....	59
3.4.2.	Insertion	59
3.4.3.	Bundle material cutting	59

4. ÚDRŽBA STROJE / MACHINE MAINTENANCE / WARTUNG ..60

4.1.	Saw band dismantling.....	62
4.2.	Saw band installation	64
4.3.	Saw band stretching and inspection	66
4.3.1.	Saw band stretching.....	67
4.3.2.	Saw band inspection.....	67
4.4.	Adjustment	68
4.4.1.	Saw band run adjustment.....	68
4.4.2.	Hard metal guides adjustment on the machine	68
4.4.3.	Guide cube adjustment.....	69
4.4.4.	Brush adjustment.....	69
4.4.5.	Adjusting the limit switch of the saw band stretching.....	71
4.4.6.	Saw frame lower position stop adjustment	72
4.4.7.	Adjustment of the limit switch of saw frame lower stop.....	72
4.5.	Cooling agents and chip disposal	73
4.5.1.	Coolant inspection.....	73
4.5.2.	Cooling liquid preparation.....	74
4.5.3.	Chips disposal.....	74
4.6.	Gearbox oils and greases.....	76
4.6.1.	Gearbox oils	76
4.6.2.	Lubrication greases	77
4.6.3.	Lubrication.....	77
4.6.4.	Hydraulic oils.....	78
4.7.	Machine cleaning.....	78
4.8.	Worn pieces replacement.....	79
4.8.1.	Hard metal guides replacement.....	79
4.8.2.	Saw band guiding rollers replacement.....	80
4.8.3.	Worn brush replacement.....	82
4.8.4.	Stretching wheel replacement.....	83
4.8.5.	Driving wheel replacement.....	85
4.8.6.	Cooling pump replacement.....	86

5. ZÁVADY / TROUBLESHOOTING / STÖRUNGEN89

5.1.	Mechanical problems.....	91
5.2.	Electrical problems.....	93
5.2.1.	Hydraulic problems	94

6. SCHÉMATA / SCHEMATA / SCHEMATICS98

6.1.	Elektrická schémata / Elektroschemas / Wiring diagrams –3×400 V + PE, 50Hz –frekv. měnič / Frequenzumrichter / frequency convertor	100
6.2.	Elektrické schéma /Elektroschema /Wiring diagrams – – 2×230 V + PE, 50Hz –frekv. měnič / Frequenzumrichter / frequency convertor	113
6.3.	Hydraulické schéma Hydraulisches Schéma Hydraulic diagram.....	128

7. VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER.....132

7.1.	Ergonomic 340.278 DG.....	134
7.2.	Kusovník / Piece list / Stückliste - Ergonomic 340.278 DG.....	135
7.3.	Ergonomic 340.278 DG.....	136
7.4.	Kusovník / Piece list / Stückliste - Ergonomic 340.278 DG.....	137
7.5.	Chlazení / Cooling / Kühlung.....	138
7.6.	Kusovník / Piece list / Stückliste - Chlazení / Cooling / Kühlung	139
7.7.	Ovládací panel / Control panel / Bedienpult.....	140
7.8.	Kusovník / Piece list / Stückliste - Ovládací panel / Control panel / Bedienpult	141

7.9. Doraz / Stop piece / Anschlag.....	142
7.10. Kusovník / Piece list / Stückliste - Doraz / Stop piece / Anschlag.....	143
7.11. Podstavec / Base / Untersatz	144
7.12. Kusovník / Piece list / Stückliste - Podstavec / Base / Untersatz	145
7.13. Konzola otočná / Turnable consol / Drehkonsole.....	146
7.14. Kusovník / Piece list / Stückliste - Konzola otočná / Turnable consol / Drehkonsole.....	147
7.15. Kartáč / Brush / Bürste	149
7.16. Válec zvedací / Lifting cylinder / Hebezyylinder	150
7.17. Kusovník / Piece list / Stückliste - Válec zvedací / Lifting cylinder / Hebezyylinder	151
7.18. Stůl / Table / Tisch.....	152
7.19. Kusovník / Piece list / Stückliste - Stůl / Table / Tisch	153
7.20. Svěrák / Vice / Schraubstock	154
7.21. Kusovník / Piece list / Stückliste - Svěrák / Vice / Schraubstock.....	155
7.22. Doraz / Stop piece / Anschlag	156
7.23. Kusovník / Piece list / Stückliste - Doraz / Stop piece / Anschlag.....	157
7.24. Rameno / Saw arm / Sägerahmen	158
7.25. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen.....	159
7.26. Rameno / Saw arm / Sägerahmen.....	161
7.27. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen.....	162
7.28. Pohon / Drive / Antrieb	163
7.29. Pohon / Drive / Antrieb	164
7.30. Vedení pásu / Belt guide / Sägebandführung.....	165
7.31. Kusovník / Piece list / Stückliste - Vedení pásu / Belt guide / Sägebandführung	166
7.32. Kostka vodící / Lead cube / Führungsklotz	167
7.33. Kostka vodící / Lead cube / Führungsklotz	168
7.34. Napínání / Tensioning / Spannung	169
7.35. Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung.....	170

1. **Bezpečnostní pokyny / Safety notes / Sicherheitshinweise**

The operating instructions must be read by any person, who gets in touch with the machine during transportation, installation, using, servicing, repair, stocking or removal!

Attention!

The operating instructions must be available at the machine position! Keep the operating instructions in a good condition!

The operating instructions include relevant information. The operator must familiarize himself with the installation and operation, safety notes and machine servicing, to reach maximum reliability and lifespan. The operating instructions serve to avoid risks, which are linked with work on the machine. Before transporting and using the machine, please read the instructions thoroughly!

1.1. Machine determination

The band saw **Ergonomic 340.278 DG** is determined for cutting and shortening of rolled bars and drawn bars as well as profiles from steels, stainless steels, non-ferrous metals and plastics **with cutting angles -45° to 60°**.

Combustible materials are excluded from cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

The machine is equipped with safety and protective measures for both the operator and the machine to be protected. Nevertheless, these measures cannot prevent all injuries. All personnel must read this chapter and understand it, before they start to work on the machine. **Always follow the instructions about work safety!** The personnel must take into account other aspects of the risk, which include the conditions of the working place and the material.

1.2. Protective clothing and personal safety

Wear fitting clothes! Loosely fitting clothes may be caught in the moving machine parts and cause serious injuries.

Attention!

Gloves can be worn only when manipulating with the material or replacing parts! The machine and its accessories must be inactive!

If the machine is running, you must not wear gloves! There is a higher risk of getting caught in the moving machinery!

Wear protective gloves! Material cuts and saw band have sharp edges and may cause injuries.

Wear protective shoes with non-skid soles! Unsuitable shoes may cause balance loss and following injury. Falling pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protection! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

Attention!

Mind the safety signs on the machine. Do not remove or damage them!

Attention!

*Machine can be operated by person older than 18 years!
Machine can be operated only by a person physically and mentally fit for this activity*

Follow the instructions and orders about work safety!

Read the operating instructions, before you start to work on the machine! Keep the operating instructions in good condition!

1.3. Safety notes for machine operator

Machine can be operated only by one person. Machine operator is responsible for other people present near the machine.

Close covers before starting the machine and check, if the covers are not damaged. Damaged covers must be repaired or changed immediately. Do not start the machine, if the cover is removed! Check, if the electric cables are not damaged.

- Do not hold the material for clamping in the vice and when cutting!
- Do not operate the buttons and switches on the control panel, when you have gloves!

Attention!

Do not connect the machine to electricity if the covers are removed. Do not touch the electrical equipment or wiring.

- For machine starting take care, that there is nobody in the working area of the machine (the working area of the vice, the saw band, the saw arm etc.).
- Under no circumstances touch the rotating elements.
- Work on the machine only when the machine is in good condition!
- Check at least once in a shift, if the machine is not damaged. If the machine is damaged, you must bring the machine to a halt and inform your superior!
- Keep your working area clean! Ensure sufficient lighting in the working area.
- Take off the spilt water or the oil from the floor and dry it. Do not touch the cooling liquid with bare hands! Do not set the nozzle of the cooling liquid, when the machine is started running.
- Do not remove the chips from the working area of the machine, when the machine is running!

- Do not use compressed air for the machine cleaning or for the chip removal!
- Use the protective instruments for chip removal!

1.4. Safety notes for the servicing and repairs

Switch off the main switch and lock it, before you start service work! Otherwise, there is a possibility of starting the machine accidentally.

Only qualified person can do the servicing and repairs. For parts replacement, use only those, which are identical with the originals. Otherwise, there is possibility of health hazard. Use only recommended types of hydraulic oils, oils and lubricants!

Attention!

Only a qualified professional can carry out the servicing and repairs of the electrical equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always follow the work safety instructions! Otherwise, there is possibility of heavy injury!

Do not remove lock the limit switches or safety equipment! Any use of the saw, accessories or machine parts other than that intended by the BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be lost afterward and BOMAR, spol. s r.o. takes no responsibility for damage caused.

1.4.1. Safety notes for the servicing and repairs on hydraulic unit

Compliance with the principles of cleanness is a basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are products made with high precision, and any contamination leads to a reduction of lifetime and even malfunction. The consequences are very difficult and expensive to remove.

Always use clean tools. Never put parts and fasteners which are a part of the hydraulic circuit on a dirty surface. The best cleaning agent is crepe paper. The fibers of the cleaning cloths can also cause malfunction.

Remove the protective caps from the threaded chamber just before the assembly of the unit.

Flush hoses and pipes before mounting with gasoline or other cleaning agent and blow compressed air through them.

All fittings must be properly tightened. However, do not use brute strength.

Attention!

- *When handling the coolant always keep to the work safety directives and instructions of the manufacturer.*
- *When handling cooling agents always wear safety fluid-proof gloves!*
- *Wear protective goggles!*
- *Cooling liquid can get in contact with your eyes and may cause permanent severe injuries*

1.5. Safety notes for the cooling

1.5.1. Instructions for first aid

1. Pull off and safely remove polluted, soaked clothing.
2. If inhaled, go out on fresh air or look for first aid treatment.

3. Wash with water and eventually treat with crème any points of contact with the skin.
4. Flush your eyes with water and seek out a doctor.
5. If swallowed, drink a lot of water and induce vomiting. Look for medical help

1.6. Safety machine accessories

The machine is equipped with safety accessories. They protect the operator from injuries and the machine from damage. The safety accessories are blocking accessories, emergency switches and covers. Check the function of the safety accessories once a week. If the safety accessories are not fulfilling their function, stop your work and repair or change the safety accessories.

Enhanced risk!

Do not come into or intervene in the cutting area. Otherwise, there is a possibility of heavy injury.

1.6.1. Total Stop


TOTAL STOP button is used for emergency switching – off of the machine in a case of defect or health hazard. By pressing the **TOTAL STOP** button the supply of the electrical power is interrupted.

If any damages or fault appear, immediately press the **TOTAL STOP** button!



Release of the pressed button is possible by turning the upper part of the button.

1.6.2. Arm cover



If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The machine cannot be run with the arm open even in the service mode.



Make sure the arm cover is closed before starting the machine!



1.6.3. Saw band covers

These three covers cover the band of the saw

- from the moveable guiding cube to the arm



- from the jaw of the vice to the arm (both sides)



Never turn the band drive on, if these covers are not mounted


1.6.4. Saw band stretching and rupture inspection

This device checks the saw band stretching and causes an immediate machine shut – down in case the band ruptures.




The device contains a limit switch. Its setting is described in the chapter Machine maintenance. Check the stretching carefully and periodically and adjust it eventually.

1.7. Umístění štítku stroje /
Maschinenschild position /
Position of the machine label








1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols



2. **Dokumentace stroje / Machine documentation / Dokumentation der Maschine**


2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:				
• Hmotnost / Gewicht / Weight	372 kg			
Rozměry stroje / Maschinengröße / Machine size :				
• Délka / Länge / Lenght	1960 mm			
• Šířka / Breite / Width	1570 mm			
• Výška / Höhe / Height	1770 mm			
Elektrické vybavení / Elektrische Ausrüstung / Electical equipment:				
• Napájení / Versorgungsspannun / Supply voltage	~ 3×230/400V, 50Hz			
• Příkon / Gesamtschlusswert / Total Input	1,7 kW			
• Max.jištění / Max. Vorschaltsicherung / Max. Fuse	16 A			
• Krytí / Schutzart / Protection	IP 54			
Akustický tlak / Schalldruckpegel / Acoustic pressure:				
• Ergonomic 340.278 DG	L _{Aeqv} 59 / 65 dB*			
Pohon / Atrieb / Drive:				
• Typ / Typ / Type	FC90L-4			
• Výkon / Leistung / Output	1,5 kW			
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed	1390 min ⁻¹			
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:				
• Výkon / Leistung / Output	0,05 kW			
• Obsah nádrže / Volumen vom Kühlmittel / Capacity	20 dm ³			
Rozměr pásu / Sägebanddimension / Band size:				
2910×27(25)×0,90 mm				
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:				
20–120 m/min				
Řezné rozsahy / Schnittbereiche / Cutting size:				
				
0°	 Ø275	 340 x 100	 280 x 275	 275x275
R 45°	Ø225	225 x 100	195 x 250	205x205
L 45°	Ø205	220 x 100	150 x 275	180x180
R 60°	Ø140	140 x 110	140x110	110 x 110


*Hladina akustického tlaku:

Ekvivalentní hladina akustického tlaku A (hluku) je v místě obsluhy $L_{Aeqv} = 59/65 \text{ dB}$. Uvedené hodnoty jsou hladiny emise a nemusí představovat bezpečné pracovní hladiny. Faktory, které ovlivňují skutečnou hladinu expozice pracovníků, jsou vlastnosti pracovní místnosti, zpracovávaný materiál a použité pilové pásy, které mohou expozici významně ovlivnit.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Follow the recommendations of the manufacturer for transportation and stocking! If the recommendations are not kept, damage may occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have a license for it!
- Don't move under suspended loads! Fault in the lifting device may cause serious injury.
- Keep a safe distance from the machine during transport.
- Temperature of the air must be between **-25°C and 55°C**, for a *short period* (max. 24 hours) up to 70°C.
- Do not expose the machine to radiation (microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating of the condition of the insulation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all smooth surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.

Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.

Put the stickers stating the minimum approximate machine weight to at least five well visible places.

The machine has to be screwed to a pallet for the transportation. Make sure the pallet is strong enough to be able to hold the saw!


2.4.3. Transport and stocking

The machine must be secured during transportation. Screw the pallet to the floor of the vehicle. Be careful that the machine is not damaged during transportation.. It is forbidden to handle the machine in any way different from that written in these operating instructions, the machine can be damaged.



Store the machine only under conditions mentioned in the manual, to avoid damage of the machine

2.4.4. Transportní schéma /
Transport schema /
Transport diagram



2.5. Activation

2.5.1. Machine working conditions

Keep the conditions of the manufacturer for machine operation! If the recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At air temperature from **10°C to 40°C**; the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the interval from 30% to 95% (not condensing). Altitude up to 1000 meters.
- Do not expose the machine to any radiation (microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorate the condition of the insulation.

2.6. Band saw unpacking and assembling


1. Remove the wrapping from the machine and unpack all parts.

Attention!


Switch off the main switch and lock it in position, before you start the assembly! Otherwise, there is a possibility of an accidental machine start.

2. Now put all enclosed parts to place.


2.6.1. Installation of the length stop for the material length setting




1. Slide the length stop into the hole on the side of the vice.



2. Move the length stop up to the saw band.



3. Set the measuring unit to zero value.



4. Fix the guiding pole of the length stop in place with a screw, which is put into the opening on the top side of the vice.

2.6.2. Attachment of the cooling liquid tub




1. Put the tub for the dripping off of the coolant on the pedestal from the back side of the saw



2. Attach the hose for the coolant removal to the outlet of the tub and put its other end into the coolant tank.

2.6.3. Assembly of the hand wheel



Remove the nut from the handle of the hand wheel, place it into the hex opening on the back side of the wheel and fasten the handle.

2.6.4. Machine installing and leveling

Check the floor supporting capacity before installing the machine. If the floor capacity does not meet the requirements, you must ready the necessary base for the machine.

Minimal requirement:

machine weight – Ergonomic 340.278 DG – 372 kg

+ weight of the accessories


+ maximum weight of material

- The machine must be leveled in a horizontal position. All feet of the machine must touch the floor after leveling.
- The machine must be leveled by means of a calibrated spirit level. Put the spirit level near the vice. Adjust the roller conveyors according to the spirit level.
- For machine leveling, take care that there is sufficient space available for operation, repair work, servicing of the machine and handling of the material.
- The machine and all appended parts and accessories must be visible from the place of operation.

2.6.5. Machine disposal after lifetime

Pour all service fluids (cooling liquid, hydraulic oil) from the machine over into designated reservoirs. Dismantle machine into separate parts and dispose of them in accordance with valid directives.

2.6.6. Kotevní plan / Verankerungsplan / Grounding plan



Kotvicí materiál / Verankerungsmaterial / Grouding material

- Hmoždina / Dübel / Plug - 4x
- Vrtáno/ Gebohrt/ Drilled 4x Ø14 mm - do hloubky / In die Tiefe / to depth - 100 mm
- Závitová tyč / Gewindestift / Handrail bolt - 4xM12x120

- Šrouby podložit deskami o min. rozměrech P10x100-100
- Die Schrauben mit Platten mit Minimaldimensionen P10x100-100 unterlegen
- Screws must be bottomed with plates (min. dimensions P10x100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.7. Electrical connection

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with the electrical equipment. High voltage accident can have fatal consequences! Always follow instructions for work safety.

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V}$, 50 Hz, TN-C-S
- Total input 1,7 kW
- Max. fuse: 16 A

Before connecting the machine turn off the main power switch and ensure a dry area for the connection work.

Note:

The values of the cross section of the conductor and the rated current can be found in the regulations.

Service voltage must agree with the line voltage! Cross section of the supply line must respond with the rated current for max. machine load.

Note:

The socket with the fork can be used only for machines with the rated current less than 16 A and total input less than 3 kVA.

The input line is equipped with a 16 A socket for connection of the machine to the electric supply line. In case the machine is connected with a direct connection, an extra main switch which can be locked in zero position must be added.

Attention!



In this case the extra switch becomes the primary switch and the main switch on the machine has only secondary function!

2.7.1. Check the direction of the saw band



After the machine has been successfully connected, switch on the machine and run the driving engine of the band briefly. The movement of the band must be in agreement with the direction of the arrow on the saw band cover. If the direction of the saw band does not agree, the phases at the terminal line must be switched.



2.7.2. Inspection of the connection to the electrical network

Attention!

When you connect the machine to the electrical network insure correct connection of all phases!

THE HYDRAULIC AGGREGATE ENGINE MUST NOT BE OPERATED IN REVERSED MODE FOR MORE THEN 10 SECONDS!!!

2.8. Filling of the cooling system

Prepare a mixture of the water and the cooling liquid. Keep to the concentration specified by manufacturer. Remove the cover from the drainage hole. Pour the mixture into the tank of the cooling system.

When filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and that the tank does not overflow.

When adding anticorrosion agents, antifreeze and other chemicals follow the instructions of the manufacturer! By mixing various products poisonous and aggressive chemicals can be created that can damage your health or the cooling equipment of the machine.

2.9. Machine functions check

Before you start the check study the chapter *Machine control* thoroughly. Do not proceed with the check if you did not fully understand all control elements and machine functions.

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if all covers are installed and functional. Check (with the Tenzomat) if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Correct values of the saw band tension are on the Tenzomat.

Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to the other outer position. Raise the saw frame to the top position and than lower the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are run properly, the machine is ready for operation.

2.10. Saw band

Remove the saw band cover only after you have installed and tightened the saw band a bit. This way you minimize the risk of injury.



2.10.1. Saw band size

2910×27(25)×0,90 mm

2.10.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth systems. The important factor for selection of the tooth system is the length of the cutting canal with respect to the size of the product.

BOMAR recommends variable tooth system for its band saws.

5. *Constant tooth system* – the saw band has a constant tooth pitch all over its length. This type is suitable for cutting solid materials.
6. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cut area.

In the table below the type of the tooth system depending on the sizes and profile of the cutting material is advised.

Footnotes:

Z_pZ – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:

32 S – number „32“ means 32 teeth per inch (constant tooth system), letter „S“ marks teeth with zero angle with respect to the band.


4–6 K – number „4–6“ means 4 to 6 teeth per inch (variable tooth system); letter „K“ marks teeth with positive angle with respect to the band.

2.10.3. Saw band running-in

For reaching a full lifespan of the band we recommend performing a running-in.

Running-in: Perform a cut with the frame lowering speed at 50%. If vibrations occur increase or decrease the band's speed.






When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for approximately 15 minutes. When the band has been run, increase the lowering speed of the arm to normal. The running in of the saw band avoids micro chips on the cutting edges of a new saw band ensuing from first excessive stress. This would decrease its lifespan substantially. The optimal running in of the saw band produces ideal rounded








Note: *Run-in reground saw bands too.*

cutting edges and therefore the conditions for a maximum lifespan are met.

2.11. Table for teeth selection

SHAPED MATERIAL (D _p , S = mm)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to 2×S). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system (Z _p Z) Outer diameter of the profile D _p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10–14 S	10–14 S
4	24 S	14 S	10–14 S	10–14 S	8–12 S	8–12 S
5	18 S	10–14 S	10–14 S	8–12 S	6–10 S	6–10 S
6	18 S	10–14 S	8–12 S	8–12 S	6–10 S	6–10 S
8	14 S	8–12 S	6–10 S	6–10 S	5–8 S	5–8 S
10	-	6–10 S	6–10 S	5–8 S	5–8 S	5–8 S
12	-	6–10 S	5–8 S	5–8 S	4–6 K	4–6 K
15	-	5–8 S	5–8 S	4–6 K	4–6 K	4–6 K
20	-	-	4–6 K	4–6 K	4–6 K	3–4 K
30	-	-	-	3–4 K	3–4 K	3–4 K
50	-	-	-	-	-	3–4 K

Size of the wall S [mm]	Tooth system (Z _p Z) Outer diameter of the profile D _p [mm]					
	150	200	300	500	750	1000
2	10–14 S	10–14 S	8–12 S	6–10 S	5–8 S	5–8 S
3	8–12 S	8–12 S	6–10 S	5–8 S	4–6 K	4–6 K
4	6–10 S	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K
5	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K	3–4 K
6	5–8 S	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K
8	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K	3–4 K
10	4–6 K	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K
12	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K
15	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K
20	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K	2–3 K
30	3–4 K	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K
50	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K
75	-	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K	0,75–1,25 K
100	-	-	1,4–2 K	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
150	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
200	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K

SOLID MATERIAL (D = mm)						
						
Constant tooth system			Variable tooth system			
length of the cut D		tooth system (Z _p Z)	length of the cut D		tooth system (Z _p Z)	
to 3 mm		32	to 30 mm		10–14	
to 6 mm		24	20–50 mm		8–12	
to 10 mm		18	25–60 mm		6–10	
to 15 mm		14	35–80 mm		5–8	
15–30 mm		10	50–100 mm		4–6	
30–50 mm		8	70–120 mm		4–5	
50–80 mm		6	80–150 mm		3–4	
80–120 mm		4	120–350 mm		2–3	
120–200 mm		3	250–600 mm		1,4–2	
200–400 mm		2	500–3000 mm		0,75–1,25	
300–800 mm		1,25				
700–3000 mm		0,75				

3. **Ovládání stroje / Machine control / Bedienung der Maschine**

3.1. Starting the band saw and switching on the safety circuits


1. Turn the **main switch** into position 1 –ON
The main switch is located on the side of the control panel..





2. **Switch on the Safety circuit of the saw.** The safety circuit will run a check on all safety switches.



3.2. Control elements



1	TOTAL – STOP button Immediately stops the machine in a case of emergency.
2	Safety circuit Press button to turn on the safety circuit
3	START Starts the drive of the saw band..
4	STOP Stops the drive of the saw band
5	Ergonomic 340.278 DG without a frequency converter  Cutting speed switch Serves to switch the speed of the saw band during cutting (40 or 80 m. min ⁻¹).
	Ergonomic 340.278 DG with a frequency converter  Frequency converter – setting of the cutting speed Serves to set the speed of the saw band during cutting with the possibility of the frequency converter (20 to 120 m. min ⁻¹).
6	Regulation valve The regulation valve sets the speed of the descent of the saw arm into the cut. The speed is limited by the setup of the pressure into the cut on the guiding cubes. Note: If the throttle valve is tightened too much when being closed, the valve seat can be worn out, which will cause leakage. Always tighten the valve gently.
7	Setting of the cooling mode of the saw band By turning the knob into the corresponding position the required cooling mode is set. See chapter regarding the setting of the cooling mode
8	Laserliner – optional equipment Laser beam switch
9	Rapid shift – optional equipment The rapid shift allows a faster descent of the arm into the cut than the maximum speed of descent reached with the hydraulic regulation. For acceleration of descent of the arm into the cut press the rapid shift button.

3.3. Machine control


3.3.1. Cutting

1. Open the main vice of the band saw.
2. Set the length stop to the desired length of the material.
3. Set the desired cutting angle.
4. Insert the material and push it to the length stop.
5. Move the vice jaw to about 5 mm from the material


For a longer distance movement of the vice jaw use the rapid shift option:




- a) loosen the arresting lever of the moveable jaw of the main vice



- b) move the jaw to the required distance
c) tighten the arresting lever



For shifting the jaw for a shorter distance use the hand wheel.




6. Tighten the material by the clamping lever.
7. Set the left guiding cube of the saw band as close as possible to the material.

Note:


It is possible to stop the saw band drive by pressing the STOP button or in a case emergency with the TOTAL STOP anytime during the cutting

8. Set the saw band speed.
9. Start saw band drive with the **START** button.
10. Set the speed of the saw frame descent.
11. Close the regulation valve of the frame descent and lift the saw frame to the top position after cutting
12. Remove the material. Now you can repeat the whole process.

3.3.2. Setting of the material length




1. Loosen the clamping screw of the length stop



2. Shift the length stop to the required length and tighten the clamping screw.




Warning!


The length stop enables a gap between the length stop slat line and the material to avoid clenching the saw band in the cut during cutting. Set the gap of the length stop by turning the lever in the direction of the arrow.





3.3.3. Setting of the cutting angle

The band saw **Ergonomic 340.278 DG** allows cutting under angles from -45° to 60° . For an easier setup of common angles, there are latches on the turning console at every 15° angle increment. Locking in the latches can be felt when turning the saw frame by hand. It is not necessary to loosen the latches for setting a different angle, just turn the saw frame console in the direction required.


Picture	Procedure
	<p>13. Raise the saw frame and loosen the turning console clamping lever.</p>
	<p>14. Set the required angle of the cut according to the scale on the turning console.</p>
	<p>15. Tighten the clamping lever of the console.</p>

Picture	Procedure
	<p>16. Loosen the clamping lever of the vice.</p>

Picture	Procedure
<p data-bbox="491 320 608 353">angle $< 0^\circ$</p>  <p data-bbox="491 1122 608 1155">angle $\geq 0^\circ$</p> 	<p data-bbox="815 1010 1166 1171">17. Shift the vice according to the set angle of the cut. For negative angles move the vice to the right, for positive and zero angles to the left.</p>



3.3.4. Setting of the optimal span of the guiding cubes

For reaching a smooth and accurate cut it is necessary to move the left guiding cube as close to the cut material as possible.



1. Loosen the lever of the left guiding lath and move the left part of the saw band guide so that the edge of the left guiding cube will be as close to the material as possible.
2. Lower the arm into the lower position and check the position of the guiding cube in respect to the loading surface. The guiding cube should be positioned approx. 10 mm from the loading surface of the vice.
3. Tighten the lever of the guiding lath and check the setting of the guiding cube one more time to avoid collision with the vice jaw or clamping table.

3.3.5. Cutting speed adjustment

Picture	Description
<p>Ergonomic 340.278 DG without freq. converter</p> 	<ul style="list-style-type: none"> speed 40 m.min^{-1} – turn speed switch no.2 on the control panel into pos. no. 1 speed 40 m.min^{-1} – turn speed switch no.2 on the control panel into pos. no. 2
<p>Ergonomic 340.278 DG with freq. Converter</p> 	<ul style="list-style-type: none"> Change band saw speed by frequency converter in range $20\text{--}120 \text{ m.min}^{-1}$.

3.3.6. Speed adjustment of the arm lowering

Set the speed of the arm lowering to the cut by this regulation knob on the control panel (no.6)

- turn clockwise to lower the speed of the descent
- turn counter clockwise to increase the speed of the descent

Warning!

If the throttle valve is tightened too much when being closed, the valve seat can be worn out, which will cause leakage. Always tighten the valve gently


Note

If the regulation valve is fully closed, the arm is fixed in a vertical position.

To allow the arm to move downwards (into cut) it is necessary to release the valve.

3.3.7. Setting the type of cooling

The required type of cooling can be chosen using knob no. 3 on the control panel.



Cooling with liquid:

1. The cooling pump runs, even if the pump is turned off (washing)
2. The saw band runs without cooling.
3. The cooling is turned on together with the saw band drive

Cooling with oil vapor- Microniser (optional equipment)

4. Saw band runs without cooling.
5. Cooling is turned on together with the saw band drive.

3.4. Material insertion


- Never walk under a suspended load!
- Never climb onto the roller conveyor!
- Do not hold the material for clamping in the vice! The vice can cause injuries!

3.4.1. Selecting means of manipulation

- Use the sufficient means to lift and transfer the material!
- Handle the material only with a lift truck or use suspension strands and a crane!
- Do not use the lift truck or crane in case that you do not have the license to operate it!

3.4.2. Insertion

Insert material into the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you are cutting long pieces (for example rods, tubes), you must use a roller conveyor for shifting the material to the band saw. Contact Bomar for more information about roller conveyors.




Make sure the conveyor is long enough and the material cannot drop off the conveyor.

Make sure round pieces always stay on two vertical rollers and cannot fall off the conveyor!

3.4.3. Bundle material cutting

If you want to cut the material in bundles, it is suggested to load the material in the following way.

Round material bundle: For round material take care that the bars are put according to the picture. If the bars are put differently, they might slide during handling.



It is recommended to always weld the material at the rear end of the bundle to secure it from moving. Before welding always, switch the machine off with the main switch! The magnetic fields, which occur during welding, may damage the controls!


4. **Údržba stroje / Machine maintenance / Wartung**

4.1. Saw band dismantling


1. Lift the arm to its uppermost position and lock the arm in position with the regulation valve.




2. Remove the yellow safety covers of the band. The covers are tightened with screws.




3. Open the back cover of the arm. It is mounted with two plastic head screws.




4. Loosen the holder of the brush and turn it away from the band so it does not hinder the dismantling of the band.



5. By turning the tightening star to the left loosen the stretching of the band.




6. Pull the saw band from the wheels.





7. After that pull out the band carefully from the guiding cubes.

4.2. Saw band installation


1. Prior to installation, clean the track wheels, guiding cubes and inner side of the arm thoroughly of all traces of chips and dirt. *Keep in mind the teeth direction when installing the saw band.*




2. Insert a new saw band in the guide cubes. Make sure the saw band runs between both guiding rollers and that it is pushed all the way to the top.




3. Put the saw band on both guiding wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Push the saw band as close to the rim as possible..




4. Turn the tightening star to the right until you gently stretch the band. Now you can remove the plastic cover on the saw band.



5. Adjust the brush to the saw band and tighten the holder screws.



6. Close the back cover and secure it with two plastic head screws.



7. Mount the yellow safety covers of the band.



Arrow on the cover must agree with the direction of the teeth. If it does not, you have to flip the saw band.

4.3. Saw band stretching and inspection

Correct saw band stretching is one of the most important factors, which influences accuracy and saw band lifespan. Stretch the saw bands according to the band saw and the selected saw band type. Keep to the recommendation of your manufacturer.

Pilový pás Sägeband Saw band	Napětí pilového pásu Sägebandspannung Blade tension	Napětí pilového pásu PSI (pro Tenzomat) Sägebandspannung PSI (für Tenzomat) Blade tension PSI (for Tenzomat)
20 x 0,9 mm	160 N.mm ⁻²	23 500
27 x 0,9 mm	180 N.mm ⁻²	26 500
34 x 1,1 mm	210 N.mm ⁻²	30 500
41 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,6 mm	280 N.mm ⁻²	40 600
67 x 1,6 mm	290 N.mm ⁻²	42 000
80 x 1,6 mm	300 N.mm ⁻²	43 500


4.3.1. Saw band stretching

1. After installation of the saw band stretch it gently, so it does not fall of the wheels.



2. Mount the Tenzomat on the saw band and secure it with screws.
3. Stretch the saw band until it is stretched to the recommended value.


For a quick control of the tension of the band there is an indicator near the tightening star. If the indicator agrees with the picture bellow, the band is stretched correctly.



4.3.2. Saw band inspection

If the band does not run correctly, following problems can appear:


- The band falls down from the wheels – the band or the protective cover of the band can be damaged.
 - The band runs on the rim of the stretching wheel – the band or the rim of the wheel can be damaged.
1. Switch on briefly the saw band drive and then switch it off
 2. Disconnect the saw from the electrical network.
 3. Open cover of the wheels and check the position of the saw band on the both wheels.



- If the distance between backside of the saw band and the wheel rim is **1 mm**, the setting is right.
 - If the distance is bigger than **1 mm**, or the saw band runs on the rim of the wheel, adjust the saw band.
4. Close the cover.

4.4. Adjustment

4.4.1. Saw band run adjustment




The saw band run is set with screw in the stretching cube on the saw frame.
Optimal distance has been determined at **1mm**

- Turn the screw to the right, the saw band closes to the stretching wheel rim
- Turn by screw to the left, the saw band departs from the stretching wheel rim

After setting check the saw band run again.

4.4.2. Hard metal guides adjustment on the machine

Hard metal guides adjustment is one of the most important criterions which influence cutting accuracy and saw band lifespan. Therefore it is essential to check that the adjustment of the hard metal guides is correct




1. Tighten the screw on the side of guide cube so that the band is loosened
2. Loosen the screw slowly and let the hard metal plate touch the band. You must be able to turn the screw by hand. Set the hard metal guiding on the right cube in the same way.
3. Make sure that the hard metal guides do not put up to much resistance otherwise the lifetime of the saw band and drive decreases.

4.4.3. Guide cube adjustment

Cutting quality and saw band life is also dependent on guide cubes adjustment

Therefore this adjustment has to be checked periodically




1. Loosen both mounting screws on the guide cubes and push it carefully to the band. Make sure the saw band is not bent; otherwise the cube will press against the band and damage it
2. Fasten both tightening screws again

Notice:


If the guide cube is correctly adjusted, the upper edge of the cube and the ruler are parallel.

4.4.4. Brush adjustment

The brush has essential influence on cutting performance, saw band lifetime, lifetime of the wheels and hard metal guides and cutting accuracy. Therefore the brush has to be checked every shift.



1. Release the tightening screw of the brush so that it is possible to move the brush.



2. Adjust the brush to the saw band. **Its ends must not reach the saw band teeth bottoms.**
3. Tighten the screw again and turn on the band driver. If the chip removing brush is correctly fastened the brush turns smoothly with the saw band.

Do not tighten the screw with brute force!

Attention!

Do not tighten the screw with brute force!

4.4.5. Adjusting the limit switch of the saw band stretching



After the saw band is replaced, the limit switch setting must be checked. If the limit switch is not set correctly, the band is stretched either too much or too little.



1. Stretch the band with help of the TENZOMAT to an optimal value (Tenzomat chart)
2. Release the nut on the stop screw
3. Start the band drive. Two scenarios may occur:
 - a) If the engine is switched on, but it does not run, turn the screw to the left until the engine starts to run
 - b) If the engine runs turn the screw to the right until it stops, then turn the screw shortly to the left until the engine starts running again
4. Lock the stop screw using locking nut and check the adjusting of the limit switch again

4.4.6. Saw frame lower position stop adjustment

The lower stop limits the lowest position of the saw frame. This stop has to be checked at least once a month. If the lower stop is adjusted incorrectly, the loading surface of the table can be cut too deeply or the material will not be cut completely



1. Raise the saw frame to the upper position
2. Release the nut of the adjusting screw and adjust the stop
3. Fasten the adjusting screw with the nut again
4. Set the limit switch of the lower arm position


4.4.7. Adjustment of the limit switch of saw frame lower stop

If you have adjusted the lower stop of the saw frame, the limit switch adjustment inspection is required

Setting check

Lower the arm to the lowest position. If the arm lays on the lower stop and the switch reacts, the setting is correct. In other case carry out the switch setting

Switch setting



1. Release the nut of the stop screw and screw down the stop screw
2. Lower the arm to the lower stop and turn on the band driver
3. Screw out the stop screw until the band driver stops
4. Secure the screw with nut again and check the limit switch setting once more

4.5. Cooling agents and chip disposal

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
<ul style="list-style-type: none"> • use of contaminated water • impurities • oil contamination from the outside (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration 	<ul style="list-style-type: none"> • corrosion protection is diminished • lubrication decreases • microbial attack is more likely 	<ul style="list-style-type: none"> • the cooling ability is decreased • foam production increases • emulsions stability deteriorates • sticky residue develops

4.5.1. Coolant inspection

The state of the cooling agent has a significant influence on the cutting quality and on the lifespan of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution of the cooling liquid (especially with oils) and on other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be replaced.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	check concentration, add water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or replace coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides; clean the system with a cleanser* prior to the coolant replacement
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquire the supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, fix with defomer

* According to manufacturer's instructions

4.5.2. Cooling liquid preparation

Prepare a mixture of water and cooling liquid. Conform the notes of the manufacturer and keep the manufacturer's-approved concentration

All instructions are stated on the tank of the cooling liquid or in documentation of the cooling liquid. For cooling liquid usage and disposal heed the instructions of the manufacturer.

Fill the mixture of water and cooling liquid to the tank of the cooling system

When filling the tank with the cooling liquid take care that the liquid will not drip out of the tank and the tank does not overflow

Keep to the manufacturer specified recommendations for adding the anticorrosive agents, the antifreeze or other agents! Mixing two chemicals can produce toxic and aggressive substances, which can damage your health or the cooling system of the machine

Note: If the machine is equipped with Microniser (see. **Special accessory**), fill the tank of the Microniser with specified cooling liquid. Then the microniser is ready for the operation

The quality of the cooling agent will deteriorate due to:

- use of contaminated water
- impurities
- outside oil contamination (hydraulics, gears)
- high operating temperatures
- lack of air circulation
- wrong concentration

If the solution is too weak:

- corrosion protection is diminished
- lubrication decreases
- microbial attack is more likely

If the solution is too strong:

- the cooling ability is decreased
- foam behavior increases
- emulsions stability deteriorates
- sticky residue develops

4.5.3. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Put the chips into a watertight container. Make sure that the container does not leak, because even after a long dripping time, the chips still contain coolant residues.

- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid. In case the machine is equipped with micronisation device, the chips must also be handed over to a disposal company.*

4.6. Gearbox oils and greases

4.6.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Attention:

When replacing the oil, use oils recommended by BOMAR or oils from other manufacturers, which have comparable parameters.

Do not forget, that mineral and synthetic oils must not be mixed!

Use oils with DIN 51517 specification for the gearboxes. Select the ISO VG viscosity class according to the original oil.

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Ergonomic 340.278 DG	Paramo PP7	2,0 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
ÖMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.6.2. Lubrication greases


For lubrication we recommend using lithium based class NGLI-2 saponified grease. Different greases are mixable, if their oil bases and density classes are identical.

Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energrease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.6.3. Lubrication

There are several assemblies on the machine, that have to be lubricated to ensure the correct function of the machine.

Place for lubrication	Description
	<p>The upper pivot of the lifting cylinder – drip oil once a week.</p>

4.6.4. Hydraulic oils

Replace the hydraulic oil once every 2 years, because the oil properties can deteriorate and cause problems with the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Note:

When replacing the oil, use oils recommended by BOMAR or oils, from other manufacturers which have comparable parameters. Do not forget, that mineral and synthetic oils must not be mixed!

Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity class ISO VG 32 in hydraulic aggregates. Hydraulic oils quantity – see chapter Hydraulic oil level check.

Comparative table of the hydraulic oils:

Manufacturer	Type	Manufacturer	Type
Agip	Oso 32	Ina	Hidraol 32 HD
Aral	Vitam GF 32	Klüber	Lamora HLP 32
Avia	Avilub RSL 32	Hungary	Hidrokomol P 32
Benzina	OH-HM 32	Mobil	Mobil DTE 25
BP	Energol HLP 32	ÖMV	HLP 32
Bulgaria	MX-M/32	Poland	Hydrol 30
Castrol	Hyspin AWS 32	Rumania	H 32 EP
Čepro	Mogul HM 32	Russia	IGP 30
DEA	Astron HLP 4hy6	Shell	Tellus Oil 32
Elf	Elfolna 32	Sun	Sunvis 846 WR
Esso	Nuto H 32	Texaco	Rando HD B 32
Fam	HD 5040	Valvoline	Ultramax AW 32
Fina	Hydran 32		

4.7. Machine cleaning

Clean the machine off cooling agent and impurities after every shift. Conserve the guiding surfaces, mainly.


- Guiding of the clamping jaws of the main and feeder vice.
- Guiding of the feeder.
- The loading surface of the main and feeder vice
- Thread rod of the main and feeder vice

4.8. Worn pieces replacement


4.8.1. Hard metal guides replacement

If the hard metal guides cannot be adjusted, they have to be replaced.

1. Remove the cooling agent hosepipe and dismantle the saw band and saw band guiding cube.
2. Fasten the guiding cube in a vice.



3. Loosen the mounting screws using a hex key



4. Unscrew the frontal screws, which hold the hard metal guides.
5. Now insert new hard metal guides and fasten them tightly and mount the guiding cube to the guiding lath.

Attention:

The vice has to have aluminium jaws or an aluminium insert to protect the pivot from damage.


6. Install the saw band and adjust guiding cube and hard metal guides.

4.8.2. Saw band guiding rollers replacement

If the saw band is not sufficiently guided by guiding rollers and/or if the rollers are visibly worn, they should be replaced.

Attention! Guiding rollers must be replaced together on both guide cubes!

1. Remove the cooling agent hosepipe and dismantle the saw band and guiding cube.



2. Grip the guide cube in a vice and screw out both fastening screws of the eccentrics.



3. Pull both guiding rollers from the eccentrics.



4. Put new guiding rollers on the eccentrics and mount the eccentrics to the guide cube.



5. Now insert a test piece of saw band (cca 15 - 20 cm) into the guide cube. Adjust both eccentrics so that the band runs in the middle of the milled groove. This groove is located between both eccentrics. Guide rollers may not

Optimal distance between the band and guiding roller is 0,05 mm.


press too much against the band but spin freely.



6. Adjust the hard metal guides accordingly for the band to be able to move freely between them. Tighten the frontal screws of the hard metal guides, then tighten the mounting screws.
7. Now it is necessary to tighten the screws band guiding rollers.
8. Install the cube on the lath. Install the saw band and adjust the guiding cubes.

4.8.3. Worn brush replacement


If the chip removing brush is so worn, that it does not fulfill its function, it must be replaced.



1. Release the nut of the brush, exchange the worn brush for a new one and screw the nut.
2. Set the brush to the saw band.

4.8.4. Stretching wheel replacement

1. Dismantle the saw band.



2. Screw off the stretching wheel screw and remove the washer.
3. Screw the auxiliary screw onto the shaft of the stretching wheel.



4. Put on the three-leg puller on the stretching wheel and pull off it from the shaft.



5. If the lower bearing stays on the shaft, pull of it from the shaft with a two-leg puller. Check both bearings; eventually replace them for new ones.



6. Insert the retaining ring into the hole of the new stretching wheel.

7. Insert a bearing into the hole in the wheel and push it to the retaining ring.



8. Clean the shaft and oil it. Install the new stretching wheel on the shaft.



9. Install the distance ring on the shaft and push it to the lower bearing.



10. Install second bearing on the shaft and push it to the distance ring.



11. Install the washer and screw on the stretching wheel.
12. Install the saw band. Wheel replacement is done.

4.8.5. Driving wheel replacement

1. Dismantle the saw band.



2. Screw of the fastening screw of the driving wheel and pull off the washer.
3. Screw on the auxiliary screw to the driving shaft.




4. Install the three-leg puller on the driving wheel and pull off it from the shaft.



5. Check, if the spring and the driving shaft are not damaged. Contact your supplier for parts replacement.



6. If the shaft and the feather are in good order, clean them, oil them and install them on the driving shaft.




7. Install the washer and screw on the driving wheel.
8. Install the saw band.



4.8.6. Cooling pump replacement

Warning!
Only a qualified technician can perform the installation!
Electrical accidents can be fatal!

1. Disconnect the machine from electrical network.
2. Pull out the tank from the pedestal as far as possible.



3. Pull out the cooling pump from the tank and disconnect the hose for the coolant distribution from the pump.



4. Disconnect the supply cable of the pump from the connector.



5. Complete the replacement by following these steps in reversed order.

5. **Závady / Troubleshooting / Störungen**

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment”
	- Worn hard metal guides.	Replace according to the chapter „Worn pieces replacement”
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment”
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement”
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment”
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement”
	- Insufficient saw band stretching.	Increase the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band; follow the instructions of the manufacturer for new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Adjust the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding rail and guiding cube are loosened.	Tighten the guiding rail.
	- Guiding rail and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast rate of movement into the cut.	Lower the material speed of descent of the arm.
2. The cut is not cut upon desired angle	- Unexpected oscillation in material quality.	Adjust the cutting parameters and feeding speed according to the material.
	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment”.
	- Set angle does not match the cutting angle.	Check the angle adjustment with a protractor and if need be adjust it according to chapter „Servicing and adjustment”.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment”.
	- Guiding cube holder and guiding cube are loosened.	Fasten the guiding holder and the cube.
3. Short lifetime of the saw band	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
	- Insufficient saw band stretching.	Increase the tightening of the saw band and set the sensor of saw band tightening according to chapter „Servicing and adjustment”.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive wear as described in chapter „Worn pieces replacement”
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment”

Problem	Possible causes	Repair
	- Over stretched saw band	Lower the stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw band.	Check the condition of the hard metal guides and if they are too worn, replace hard metal guides according to chapter „Worn pieces replacement“
	- Worn saw band guide bearings.	Check the guiding bearings and if you notice any excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set the guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted speed of descent of the arm and saw band speed.	Adjust the descending speed and speed of the saw band according to values published by the saw band manufacturer.
	- Different material quality.	Adjust the speed of descent and speed of the saw band according to desired material (perform a test cut).
	- Low quality saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band, keep to the instructions of the manufacturer.
	- Wrongly adjusted run of the saw band.	Check the space between the top of the saw band and driving wheel. Adjust the tracking as described in chapter „Servicing and adjustment“ if need be.
4. Insufficient cut output.	- Worn saw band.	Replace the saw band, keep to the instructions of the manufacturer.
	- Wrong saw band tooth system.	Replace the saw band, keep to the instructions of the manufacturer.
	- Wrongly adjusted speed of descent of the arm and saw band speed..	Adjust the descending speed and speed of the saw band according to values published by the saw band manufacturer
5. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messy.	Cleanse the stop point surface of the limit switch from debris and residue material.
6. Regulation valve cannot be turned	- Metal chips between the valve and the panel.	Chips must be removed, then put an O-Ring of about 10x2 mm onto the shaft.
	- There are metal chips inside the valve.	Valve must be cleaned or changed.
7. Saw band drive cannot be started.	- Pressure switch is wrongly adjusted.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
8. Saw bands tend to rupture.	- Saw band run not adjusted properly	Adjust the distance of band from the rim according to operating instructions.
	- Wrongly adjusted band guiding (hard metal and bearings).	Hard metal pieces and bearings must be adjusted according to „Servicing and adjustment“.

Problem	Possible causes	Repair
	<ul style="list-style-type: none"> - Looseness in the lifting cylinder mounting. - Bearings of guiding cubes are worn out (rolling elements are damaged or outside ring of bearing has conical form). 	Bearings of guiding cubes must be replaced. Bearings must be adjusted according to operating instructions.
	Worn out pin of the upper or bottom holder of the lifting cylinder.	Exchange the upper or bottom holder of the lifting cylinder.
9. Damage tooth system of the saw band	<ul style="list-style-type: none"> - Geometry of hard metal guiding cubes is wrongly adjusted. - Bearings of guiding cubes are worn out. 	Hard metal guiding cubes must be adjusted. Bearings of guiding cubes must be replaced.
10. The saw is cut downing.	<ul style="list-style-type: none"> - Grooving on the driving wheel is worn-out. 	Driving wheel must be replaced.
11. Cleansing of the saw band is not functional.	<ul style="list-style-type: none"> - Elastic wheel of the brush drive is worn-out. 	Elastic wheel of the brush must be replaced.
	<ul style="list-style-type: none"> - The shaft of the brush drive is rusted. - The brush position and the brush cover is adjusted incorrectly – the cover prevents the brush from turning. 	The shaft of the brush must be cleaned and oiled. The brush cover must be repositioned, in order for the brush to be able to turn.
12. The saw arm periodically rises and descends a few millimeters during the cut; this shortens the lifetime of the saw band considerably.	<ul style="list-style-type: none"> - Backlash in driving wheel mounting on the shaft. - Worn channel for spring. 	Replace following parts: the driving shaft for a longer one, bearings, distance ring, driving wheel, spring, two covers on the forehead of the shaft + screws.

5.2. Electrical problems

Problem	Possible causes	Repair
1. Machine is not possible to start.	- No voltage in the socket	Line voltage must be checked.
	- Overload relay is defective (thermal protection)	Each FA overload relay's condition (on/off) must be checked.
	- Limit switch of either saw band stretching, band cover or saw arm is not closed	Check the saw band stretching and covers.
2. When the cut is finished, the frame is not raised.	- Bottom limit switch is adjusted wrongly.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- A malfunction in the hydraulic (pneumatic) system. The HYTOS (BOSCH) magnetic valve is not working.	Function of magnetic valve must be checked, valve must be switched on, and voltage across its terminals and coil must be checked.
3. Electric motor and pump are without voltage. There is no	- Wrong contactor.	Replace the contactor of the engine.

Problem	Possible causes	Repair
voltage between the contactor and thermal protection		
4. The speed indicator of the saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be replaced.
	- Defective sensor – diode of indicator speed does not light.	Sensor must be changed and adjusted.
5. Occasional switching off of the hydraulic aggregate MA3 engine protection	- Too big working pressure in the hydraulic system.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on the motor FA1starter.
7. Hydraulic aggregate is switched on but the saw arm or the main vice can't be moved	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer is allowed to do this.
8. Cooling is not active	Lack of cooling agent.	Refill the tank with cooling agent.
	- Thermal relay is defective	Replace the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and eventually cleanse the cooling system.
	- Cooling pump protection is defective	Check the protection of the cooling pump and change it if need be.
	- Cooling pump is defective.	Replace the cooling pump.

5.2.1. Hydraulic problems

Problem	Possible causes	Repair
1. Hydro generator is not supplying oil	• Reversed rotation	Check the correct connection of each phase. Reconnect the electrical phases properly.
	• Shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond to the prescribed viscosity value	Change hydraulic oil.
	• Hydro generator malfunction	Call service
	• Wrong power supply connection.	Check the correct connection of each phase. Reconnect the electrical phases properly.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately bled	Bleed the hydraulic circuit.
	• Low level of oil	Add hydraulic oil

	<ul style="list-style-type: none"> The hydro generator gasket is damaged 	Call service
3. Increased mechanical noise	<ul style="list-style-type: none"> Damaged clutch of the drive 	Call service
	<ul style="list-style-type: none"> Damaged or destroyed motor bearings 	Call service
	<ul style="list-style-type: none"> Air intake 	Check for leaks.
4. Low pressure, pump supplies oil	<ul style="list-style-type: none"> Failure on the safety valve 	Wrong settings. Check the settings and adjust the safety valve.
	<ul style="list-style-type: none"> Wear of the hydro generator 	Call service
	<ul style="list-style-type: none"> External or internal leakages 	Call service
5. Hydro generator is seized	<ul style="list-style-type: none"> Damage by solid particles in oil 	Perform oil filtration or call the service.
	<ul style="list-style-type: none"> Non-prescribed viscosity oil 	Change hydraulic oil.
	<ul style="list-style-type: none"> Wrong type of oil 	Change hydraulic oil.
	<ul style="list-style-type: none"> Exceeded lifespan of the pump 	Call service
6. Overheating oil	<ul style="list-style-type: none"> Cooler malfunction 	Check the cooler function or call service.
	<ul style="list-style-type: none"> Wear of the pump, energy is converted into heat 	Call service
7. Hydraulic valve cannot be readjusted	<ul style="list-style-type: none"> Electromagnet has no signal (voltage) - interrupted supply lines 	Perform recheck.
	<ul style="list-style-type: none"> Electromagnet coil burnt 	Replace coil – Call service.
	<ul style="list-style-type: none"> the slider of the switchboard slackens 	Replace slider – Call service

Note:**Frequency converter**

Connect the machine to electrical networks with corresponding technical parameters only.

We recommend protecting the machine with RCD protection with U characteristics, which is able to compensate changes of current escaping from the filter of the frequency converter, so that additional equipments will not be required. We don't recommend protecting the machine with a standard protection for currents smaller than 100 mA (the standard used is 30 mA) because of current escape in accordance to frequency converters used by machine. Alternative solution should be a current protection (FI) with sensitivity of 100 mA.

6. **Schémata / Schemata / Schematics**

- 6.1. Elektrická schémata / Elektroschemas / Wiring diagrams
 –3×400 V + PE, 50Hz
 –frekv. měnič / Frequenzumrichter / frequency convertor

0	1	2	3	4	5	6	7	8	9
<div>  <div> <p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p> </div> </div> <div> <h1>Ergonomic 340.278 G-DG-DGS</h1> <h2>ES-ER10F-201/202-V3.0</h2> <h3>Wiring diagram</h3> <p>3x400V + PE, 50 Hz</p> </div>									
<div>  <div> <p>BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno</p> </div> </div> <div> <p>Scop/Machine/Maschine: Ergonomic 340.278 G-DG-DGS</p> </div> <div> <p>Název stránky/Name page/Name seiten: Úvodní strana / Start page / Startseite</p> </div> <div> <p>Celo dok./Doc. broj/Num. der Dokumente.: ES-ER10F-201/202-V3.0 Napájení/Power supply/Einspeisung: 3x400V + PE, 50 Hz Zpracování/Processed/Has verarbeitet: Kouta Datum/Date/Datum: 9.3.2016</p> </div> <div> <p>Leaf/Page/ Str.: 1 Leaf/Page/ Seite: 12</p> </div>									

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	9.3.2016
2	Obsah / Table of contents / Inhaltsverzeichnis	9.3.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
4	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	9.3.2016
4.a	Rozmístění prvků v ovládacím panelu OP1 / Deployment of elements in control panel OP 1 / Einsatz der Elemente in dem Bedienfeld OP 1	9.3.2016
5	Silová část / Power part / Feld partie	9.3.2016
6	Ovládací část / Control part / Betätigungsteurkreis	9.3.2016
7	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	9.3.2016
8	Příslušenství / Accessories / Zubehör	9.3.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	BT50	ABB	91.051.063	1	/7.6
-FU1	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/5.5
-FU2	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/5.5
-FU3	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/5.8
-SW1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/6.8
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vítěk	91.041.015	1	/5.1
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vítěk	91.041.015	1	/5.1
-FU1	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/5.5
-FU2	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/5.5
-FU3	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/5.8
-FU4	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/5.4
-FU4	Pojistka trubičková - 700mA/250V, pomalá, 5x20 Tube fuse - 700mA/250V, slow, 5x20 Rohrsicherung - 700mA / 250V, langsam, 5x20	T700mA/250V	ESKA	91.230.069	1	/5.4

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	<div>Stroj/Machine/Maschine: Ergonomic 340.278 G-DG-DGS</div> <div>Název stránky/Name page/Name sheet: Kusovník artiklů / Parts list / Artikelstückliste</div>	<div>Číslo dok./Doc.No./Anzahl der Dokumente.: ES-ES10F-201/202-V3.0</div> <div>Nejvyšší/Power supply/Einspeisung: 3x400V + PE, 50 Hz</div> <div>Zpracováno/Processed /Hat. verarbeitet: Koska</div> <div>Datum/Date/Datum: 9.3.2016</div>	<div>Lis/Page/ Seite: 3</div> <div>Lis/Page/ Seite: 12</div>
--	--	--	--

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-FU5	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/5.5
-FU5	Pojistka trubičková - 700mA/250V, pomalá, 5x20 Tube fuse - 700mA/250V, slow, 5x20 Rohrsicherung - 700mA / 250V, langsam, 5x20	T700mA/250V	ESKA	91.230.069	1	/5.5
-KM11	Ministrykač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/7.8
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/7.8
-KM12	Ministrykač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/7.9
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/7.9
-PA1	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylinderensätze - 3P	E 93/32	ABB	91.241.014	1	/5.2
-QS1	Rukojeť odpínače 48x48mm - černá Handle switch 48x48mm - black Griffschalter 48x48mm - Schwarz	OHBS3PH	ABB	91.180.018	1	/5.1
-QS1	Kryt svorek Terminal shroud Klemmenabdeckung	OTS40T3	ABB	91.170.017	1	/5.1
-RE1	Patice pro relé Relay socket Relaissocket	CR-PSS	ABB	91.051.048	1	/6.5
-RE1	Patcové relé CR-P Plug-in relay CR-P Stecken Sle in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/6.5
-RE2	Patice pro relé Relay socket Relaissocket	CR-PSS	ABB	91.051.048	1	/6.8

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente: ES-EL10F-201/202-V3.0	Liš/Page/ Seiten: 3.1
			Náпряжение/power supply/Einspeisung: 3x400V + PE 50 Hz	Liš/Page/ Seiten: 3.1
			Zpracováni/Processed /Hat verarbeitet: Kostka	Liš/Page/ Seiten: 12
			Datum/Date/Datum: 9.3.2016	

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-RE2	Patčové relé CR-P Plug-In relay CR-P Stecken Sie in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/6.8
-SA1/1	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/6.3
-SA1/1	Kontaktní blok - 1NC Contact block - 1NC Kontaktblock - 1NC	M22-K01	EATON	91.061.024	1	/6.6
-SA1/2	Hlavice s otočným přepínačem - 4 polohy Head with rotary switch - 4 positions Kopf mit Drehschalter - 4 Positionen	M22 - WRK4	EATON	91.060.087	1	/6.5
-SA1/2	Upevňovací adaptér Mounting adapter Montageadapter	M22-A4	EATON	91.061.045	1	/6.5
-SA1/2	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/6.5
-SA1/3	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/6.6
-SB1	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pilz - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/7.4
-SW1	Svorka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/6.8
-TR1	Toroidní transformátor - 400V/230V/24V 175VA Toroidal transformer - 400V / 230V / 24V 175VA Ringkerntransformator - 400V / 230V / 24V 175VA	400V/230V/24V 2,5A 175VA	KARBAN s.r.o.	91.080.042	1	/5.6
-SQ3	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QKSS	KEDU	91.173.012	1	/7.4
-PA1	Pojistka válcová - 10A, 10x38, rychlá Tube fuse - 10A, 10x38, fast Rohrsicherung - 10A, 10x38, schnell	PV10 10A gG	OEZ	91.231.008	3	/5.2

The manufacturer reserves right to use an equivalent replacement device.


3.a	 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name seite: Kusovník artiklů / Parts list / Artikelsstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-EL0F-201/202-V3.0		Liš/Page/ Seite: 3.b
				Napájení/Power supply/Einspeisung: 3x400V + PE, 50 Hz		Liš/Page/ Seite: 12
				Zpracování/Processed /Hat. verarbeitet: Kaská		
				Datum/Date/Datum: 9.3.2016		

Kusovník artiklů / Parts list / Stückliste


Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ1	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/6.3
-SQ2	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/6.4
-DM1	Usměrnovací můstek - 6A, 100V Rectifier bridge - 6A, 100V Brückengleichrichter - 6A, 100V	KBU6B	SOS Electronic, spol. s ro.	91.280.019	1	/5.7
-QS1	3 pólový odpináč, 16A Disconnecter - 3P, 16A Trennschalter - 3P, 16A	OT16FT3	ABB	91.170.018	1	/5.1
-SB2	Hlavice tlačítka zelená Head green button Head green button	ZB5AA3	TELEMECANIQUE	91.060.014	1	/6.5
-SB3	Hlavice tlačítka černá Button black head Taste Mfesser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/6.6
-SB4	Hlavice prosvětleného tlačítka žlutá The button head backlit yellow Der Knopf Kopf von hinten beleuchtet gelb	ZB5AW35	TELEMECANIQUE	91.060.023	1	/7.7
-SB5	Hlavice tlačítka černá Button black head Taste Mfesser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/6.2
-SW1	Potenciometr 4K7 Potentiometer 4K7 Potenziometer 4K7	TP195 4K7-N20A	TES-Ostrava	91.283.002	1	/6.8
-FM1	Frekvenční měnič - 1,5kW, 3x400VAC Frequency converter - 1,5kW, 3x400VAC Frequenzumrichter - 1,5kW, 3x400VAC	VFD015EL43A	DELTA ELECTRONICS, INC.	91.012.122	1	/6.6

The manufacturer reserves right to use an equivalent replacement device.


 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: Napájení/Power supply/Einspeisung: Zpracování/Processed /Hat. verarbeitet: Datum/Data/Datum:	ES-EL10F-201/202-V3.0	Liš/Page/ Seiten: 3.e
				3x400V + PE, 50 Hz	Liš/Page/ Seiten: 3.e
				Kostka	Liš/Page/ Seiten: 12



107









- 6.2. Elektrické schéma /Elektroschema /Wiring diagrams –
 – 2×230 V + PE, 50Hz
 –frekv. měnič / Frequenzumrichter / frequency convertor

0	1	2	3	4	5	6	7	8	9
<div>  <p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p> </div> <div> <p>Ergonomic 320-275 GF-DGF-DGSF ES-ER10F-203-V3.0 Wiring diagram 3x230V + PE, 50 Hz</p> </div>									
 <p>BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno</p>		<p>Scyl/Machine/Machine: Ergonomic 320-275 GF-DGF-DGSF</p>		<p>Název stránky/Name page/Name seite: Úvodní strana / Start page / Startseite</p>		<p>Cela dok./Doc. Auftrags/ der Dokumenta.: Název/Prüfer s.r.o./Prüfung: Zpracování/Produkt für verwendet: Datum/Date/Datum:</p>		<p>Úd./Page/ strán. 00 Úd./Page/ strán. 10</p>	

0	1	2	3	4	5	6	7	8	9
<div></div> <div><p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p></div> <div><p>Ergonomic 340.278 G-DG-DGS</p><p>ES-ER10F-203-V3.0</p><p>Wiring diagram</p><p>3x230V + PE, 50 Hz</p></div>									
 <div><p>BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno</p></div>		Stroj/Machine/Machine: Ergonomic 340.278 G-DG-DGS		Název stránky/Name page/Name sheet: Úvodní strana / Start page / Startseite		Číslo dok./Doc.No/Anzahl der Dokumenten.: Napájení/Power supply/Einspeisung: Zpracováno/Processed /Hat verarbeitet: Datum/Date/Datum:		ES-ER10F-203-V3.0 3x230V + PE, 50 Hz Koska 9.3.2016	
								Lisť/Page/ Seite: 1 Lisť/Page/ Seite: 13	

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	9.3.2016
2	Obsah / Table of contents / Inhaltsverzeichnis	9.3.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
3.d	Kusovník artiklů / Parts list / Artikelstückliste	9.3.2016
4	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	9.3.2016
5	Rozmístění prvků v ovládacím panelu OP1 / Deployment of elements in control panel OP 1 / Einsatz der Elemente in dem Bedienfeld OP 1	9.3.2016
6	Silová část / Power part / Feld partie	9.3.2016
7	Ovládací část / Control part / Betätigungsteurkreis	9.3.2016
8	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	9.3.2016
9	Příslušenství / Accessories / Zubehör	9.3.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	BT50	ABB	91.051.063	1	/8.6
-FU1	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/6.5
-FU2	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/6.5
-FU3	Pojistka trubičková - 2A/250V, pomalá, 5x20 Tube fuse - 2A/250V, slow, 5x20 Rohrsicherung - 2A / 250V, langsam, 5x20	T2A/250V	ESKA	91.230.001	1	/6.8
-SW1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/7.8
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vítěk	91.041.015	1	/6.1
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vítěk	91.041.015	1	/6.1
-BM1	Bezpečnostní relé - 3xNO, 24VDC Safety circuit relay - 3xNO, 24VDC Sicherheitskreis-Relais - 3xNO, 24VDC	RT6	ABB	91.051.056	1	/4.6
-FU1	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/6.5
-FU2	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/6.5
-FU3	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/6.8
-FU4	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS15U	WIELAND	91.251.102	1	/6.4

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stručný popis/Machine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name sheet: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-ELDF-203-V3.0 Napájení/Power supply/Einspeisung: 3x230V + PE, 50 Hz Zpracování/Processed /Hat. verarbeitet: Koska Datum/Date/Datum: 9.3.2016	List/Page/ Seite: 3 List/Page/ Seite: 13

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-FU4	Pojistka trubičková - 700mA/250V, pomalá, 5x20 Tube fuse - 700mA/250V, slow, 5x20 Rohrsicherung - 700mA / 250V, langsam, 5x20	T700mA/250V	ESKA	91.230.069	1	/6.4
-FU5	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/6.4
-FU5	Pojistka trubičková - 700mA/250V, pomalá, 5x20 Tube fuse - 700mA/250V, slow, 5x20 Rohrsicherung - 700mA / 250V, langsam, 5x20	T700mA/250V	ESKA	91.230.069	1	/6.4
-KM11	Ministýkač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/8.8
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/8.8
-KM12	Ministýkač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/8.9
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/8.9
-PA1	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylinderinserts - 3P	E 93/32	ABB	91.241.014	1	/6.2
-QS1	Rukojeť odpínače 48x48mm - černá Handle switch 48x48mm - black Griffschalter 48x48mm - Schwarz	OHBS3PH	ABB	91.180.018	1	/6.1
-QS1	Krytí svorek Terminal shroud Klemmenabdeckung	OTS40T3	ABB	91.170.017	1	/6.1
-RE1	Patice pro relé Relay socket Relaissockel	CR-PSS	ABB	91.051.048	1	/7.5
-RE1	Patcové relé CR-P Plug-in relay CR-P Stecken Sie in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/7.5

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/machine/Maschine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-EL10F-203-V3.0	Liš/Page/ Seiten: 3.1
			Napájení/Power supply/Einspeisung: 3x230V + PE, 50 Hz	Liš/Page/ Seiten: 3.1
			Zpracováno/Processed /Hat. verarbeitet: Kostka	Liš/Page/ Seiten: 13
			Datum/Date/Datum: 9.3.2016	

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-RE2	Patice pro relé Relay socket Relaissockel	CR-P55	ABB	91.051.048	1	/7.8
-RE2	Patcové relé CR-P Plug-in relay CR-P Stecken Sie in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/7.8
-SA1/1	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/7.3
-SA1/1	Kontaktní blok - 1NC Contact block - 1NC Kontaktblock - 1NC	M22-K01	EATON	91.061.024	1	/7.6
-SA1/2	Hlavice s otočným přepínačem - 4 polohy Head with rotary switch - 4 positions Kopf mit Drehschalter - 4 Positionen	M22 - WRK4	EATON	91.060.087	1	/7.5
-SA1/2	Upevňovací adaptér Mounting adapter Montageadapter	M22-A4	EATON	91.061.045	1	/7.5
-SA1/2	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/7.5
-SA1/3	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/7.6
-SB1	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Plz - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/8.4
-SN1	Sworka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/7.8
-TR1	Toroidní transformátor - 400V/230V/24V 175VA Toroidal transformer - 400V / 230V / 24V 175VA Ringkerntransformator - 400V / 230V / 24V 175VA	400V/230V/24V 2,5A 175VA	KARBAN s.r.o.	91.080.042	1	/6.6
-SQ3	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QKS8	KEDU	91.173.012	1	/8.4

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-ELDF-203-V3.0	Lis/Pages/ Seiten: 3.b
				Napájení/Power supply/Einspeisung: 3x230V + PE, 50 Hz	
				Zpracování/Processed /Hat. verarbeitet:	
				Datum/Date/Datum:	
					9.3.2016
					Seiten: 13

Kusovník artiklů / Parts list / Stückliste


Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-PA1	Pojistka válcová - 10A, 10x38, rychlá Tube fuse - 10A, 10x38, fast Rohrsicherung - 10A, 10x38, schnell	PV10 10A gG	OEZ	91.231.008	3	/6.2
-SQ1	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/7.3
-SQ2	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/7.4
-FW1	Frekvenční měnič - 1.5kW, 3x230VAC Frequency converter - 1.5kW, 3x230VAC Frequenzumrichter - 1.5kW, 3x230VAC	VFD015E23A	DELTA ELECTRONICS, INC.	91.012.141	1	/7.6
-FW1	Frekvenční měnič - 1.5kW, 3x400VAC Frequency converter - 1.5kW, 3x400VAC Frequenzumrichter - 1.5kW, 3x400VAC	VFD015L43A	DELTA ELECTRONICS, INC.	91.012.122	1	/4.2
-DW1	Usměrňovací můstek - 6A, 100V Rectifier bridge - 6A, 100V Brückengleichrichter - 6A, 100V	KBU6B	SOS Electronic, spol. s ro.	91.280.019	1	/6.7
-QS1	3 pólový odpojovač, 16A Disconnecter - 3P, 16A Trennschalter - 3P, 16A	OT16FT3	ABB	91.170.018	1	/6.1
-SB2	Hlavice tlačítka zelená Head green button Head green button	ZB5AA3	TELEMECANIQUE	91.060.014	1	/7.5
-SB3	Hlavice tlačítka černá Button black head Taste Mitterser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/7.6
-SB4	Hlavice prosvětleného tlačítka žlutá The button head backlit yellow Der Knopf Kopf von hinten beleuchtet gelb	ZB5AW35	TELEMECANIQUE	91.060.023	1	/8.7
-SB5	Hlavice tlačítka černá Button black head Taste Mitterser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/7.2

The manufacturer reserves right to use an equivalent replacement device.

3.b	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 340.278 G-DG-DGS	Název artiklu/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: Napájení/power supply/Einspeisung: Zpracování/Processed /Hat verarbeitet: Datum/Date/Datum:	ES-ET10F-203-V3.0 3x230V + PE, 50 Hz Kostka 9.3.2016	List/Page/ Seite: List/Page/ Seite:

121


+OP1




4

	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 340.278 G-DG-DGS	Název stránky/Name page/Name sheet: Rozmístění prvků v ovládacím panelu OP1 / Deployment of elements in control panel OP 1 / Einsatz der Elemente in dem Bedienfeld OP 1	Číslo dok./Doc.No/Anzahl der Dokumente.: ES-EL10F-203-V3.0		List/Page/ Seite: 5 List/Page/ Seite: 13
				Napájení/Power supply/Einspeisung: 3x230V + PE, 50 Hz		
				Zpracování/Processed /Hat. verarbeitet: Korka		
				Datum/Data/Datum: 9.3.2016		










Schémata
Schemata
Schematics

6.3. Hydraulické schéma Hydraulisches Schéma Hydraulic diagram



POHYB VZHŮRU MANUÁLNÍ, POHYB DOLŮ VYVOZEN TÍHOU RAMENE
(RAMENO ZAVĚŠENO NA KLOUBU S KOMPENZAČNÍMI PRUŽINAMI)/
BEWEGUNG AUFWÄRTS MANUELL, BEWEGUNG ABWÄRTS MIT DEM GEWICHT
DES ARMES GESHAFT (DAS ARM IST AN DEM GELENK MIT AUSGLEICHSPERN GEHÄNGT)
UPWARD MOVEMENT OF THE SAW ARM IS MANUAL, DOWNWARD MOVEMENT IS CAUSED
BY THE WEIGHT OF THE ARM (THE ARM IS HUNG ON A JOINT WITH COMPENSATING SPRINGS)

Elektrický proud procházející cívkami/
Der elektrische Strom, der durch den Spülen fließt/
Electric current passing through the coils: 0,708 A

Typ / Type / Type

Ergonomic 320.250 DGS, Ergonomic 275.230 DGS

Neuvedené světlosti / Unerwähnt Lichtbreite / Unlisted inside diameters

Hydraulická hadice/ Hydraulikschläuche/ Hydraulic hose JS6
Pneumatická hadice/ Druckluftschlauch/ Pneumatic hose 8/6

Pmax (ventily/ ventilen/ valves 1.1, 1.2)

10 bar

Schémata
Schemata
Schematics

Poz.	Název položky	Typ	Popis	Poznámka	ks
Pos.	Bezeichnung	Typ	Beschreibung	Hinweis	Menge
Pos.	Item	Type	Description	Note	Pcs.
1	Kostka ventilů / Ventilklotz / Valve cube	92.153.071		f.FMV	1
1.1	Rozvaděč / Schaltschrank / Switchboard	Sedlový / Sitzverteilerventil/ Saddle valve /	Totalstop	Ovlád. napětí / Steuerspannung / Control voltage 24V DC	1
1.2	Rozvaděč / Schaltschrank / Switchboard	Sedlový / Sitzverteilerventil/ Saddle valve	Rychloposuv / Eilgang / Speed shift	Ovlád. napětí / Steuerspannung / Control voltage 24V DC	1
1.3	Škrťací ventil / Drosselventil / Throttle valve	Jehlový / Nadeldrosselventil/ Needle valve		Rozsah / Anwendungsbereich /Range 0 - 360° (0,1,2.....,7)	1
2	Zdvíhací válec / Hubzylinder / Lift cylinder	201.ER257-010	Bomar	Přepouštěcí / Überlaufhubzylinder / By pass cylinder	1
3	Clona / Schürze / Shield	30.0911-044	Bomar	1mm	1

Schémata
Schemata
Schematics


7. **Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order**

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix Ergonomic 340.278 DG) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Ergonomic 340.278 DG), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).

- For spare parts order, you must always to allege: type of machine (for example Ergonomic 340.278 DG), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. Ergonomic 340.278 DG

Schéματα
Schemata
Schematics



NAZEV SESTAVY
PILA PASOVA

CÍSLO SESTAVY
201.ER270-100

STROJ
ERG275

Konstruoval: MUSIL

Datum: 04. 09. 2015

Meritko: 13:100




7.2. Kusovník / Piece list / Stückliste - Ergonomic 340.278 DG

Číslo Sestavy 201.ER270-100		Ver. 2	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks	
1	201.0506-100	1	CHLAZENÍ / COOLING / KÜHLUNG		1	
2	201.0513-340	0	OVLÁDACÍ PANEL / CONTROL PANEL / BEDIENPULT		1	
3	201.0514-600	0	DORAZ / STOP PIECE / ANSCHLAG		1	
4	201.ER251-100	0	PODSTAVEC / BASE / UNTERSATZ		1	
5	201.ER252-100	0	KONZOLA OTOCNÁ / TURNABLE CONSOL / DREHKONSOLE		1	
6	201.ER257-010	0	VALEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLINDER		1	
7	201.ER259-100	0	STUL / TABLE / TISCH		1	
8	201.ER274-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1	
9	31.ER264-006	0	PRUZINA / SPRING / FEDER	d 7	1	
10	31.ER299-002	4	STÍTEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0,5x65	1	
11	41.001.006	0	HADICE / HOSE / SCHLAUCH	PG48	1	
12	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
13	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		2	
14	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
15	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
16	99.900.068	0	SAMOLEPKA / STICKER / AUFKLEBER	použití vysokozdvižného vozíčku	4	

Číslo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.3. Ergonomic 340.278 DG

Schémata
Schemata
Schematics



NAZEV SESTAVY PILA PASOVA	ČÍSLO SESTAVY 201.ER270-100	STROJ ERG275
Konstruoval: MUSIL		
Datum: 04. 09.2015		
Meritko: 13:100		


7.4. Kusovník / Piece list / Stückliste - Ergonomic 340.278 DG


Číslo Sestavy 201.ER270-100		Ver. 2	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks	
1	201.0506-100	1	CHLAZENÍ / COOLING / KÜHLUNG		1	
2	201.0513-340	0	OVLÁDACÍ PANEL / CONTROL PANEL / BEDIENPULT		1	
3	201.0514-600	0	DORAZ / STOP PIECE / ANSCHLAG		1	
4	201.ER251-100	0	PODSTAVEC / BASE / UNTERSATZ		1	
5	201.ER252-100	0	KONZOLA OTOCNÁ / TURNABLE CONSOL / DREHKONSOLE		1	
6	201.ER257-010	0	VALEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLINDER		1	
7	201.ER259-100	0	STUL / TABLE / TISCH		1	
8	201.ER274-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1	
9	31.ER264-006	0	PRUZINA / SPRING / FEDER	d 7	1	
10	31.ER299-002	4	STÍTEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0,5x65	1	
11	41.001.006	0	HADICE / HOSE / SCHLAUCH	PG48	1	
12	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
13	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		2	
14	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
15	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
16	99.900.068	0	SAMOLEPKA / STICKER / AUFKLEBER	použití vysokozdvižného vozíčku	4	

Číslo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.5. Chlazení / Cooling / Kühlung

Schéma
Schemata
Schematische



NAZEV SESTAVY CHLAZENÍ	CÍSLO SESTAVY 201.0506-100	STROJ ERG0250
	Konstruoval: NEUMANN	
	Datum: 17. 03.2016	
	Meritko: 1:5	

7.6. Kusovník / Piece list / Stückliste -
Chlazení / Cooling / Kühlung

Císlo Sestavy 201.0506-100		Ver. 2	Název sestavy CHLAZENÍ/COOLING/KÜHLUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.8006-002 (2)	0	SÍTO / SIEVE / GITTERWERK		1
2	30.8006-301 (1)	3	VÍKO / COVER / DECKEL	P 0,8 x310	1
3	42.020.003	0	HADICE / HOSE / SCHLAUCH	19x3	1
4	91.020.019 (1)	0	CERPADOLO CHLAZENÍ / COOLING PUMP / KÜHLMITTEL PUMPE		1
5	94.403.003	0	NADZ / CONTAINER / BEHALTER		1

1. ZRUS.CERPADOLO 91.020.005 A NAHR. 91.020.019, ZRUS.VÍKO 30.0506-201 A NAHR. 30.8006-301, ZRUS.SOUC. 30.0506-003,
90.100.55.004, 94.202.005, 42.020.001, 99.260.001, 94.202.002. 299/ZM274 12.11.2013 SLEZACKOVA


2. PRIDANO SÍTO 30.8006-002. 024/ZMI00 27.4.2016 SLEZACKOVA


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Verze položky/Volume title/Name der Position; Rozměr (Rozm.)/Stock size/Abmessung

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.7. Ovladací panel / Control panel / Bedienpult

Schéματα
Schemata
Schematische




NAZEV SESTAVY OVLADACÍ PANEL	CISLO SESTAVY 201.0513-340	STROJ ERGO250
	Konstruoval: FABER	
	Datum: 13. 05.2015	
	Meritko: 1:4	

7.8. Kusovník / Piece list / Stückliste - Ovladačí panel / Control panel / Bedienpult

Císlo Sestavy 201.0513-340		Ver. 0	Název sestavy OVLADACÍ PANEL/CONTROL PANEL/BEDIENPULT		
Poz.	Objednáací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0513-241	0	OVLADACÍ PANEL / CONTROL PANEL / BEDIENPULT		1
2	30.0513-320	0	NOHA / LEG / STANDER		1
3	30.2814-607	0	DRŽAK / HOLDER / HALTER		1
4	30.9307-109	1	DRŽAK / HOLDER / HALTER	P 3x25	4
5	31.0513-404	0	SAMOLEPKA / STICKER / AUFKLEBER		1
6	90.013.27.001	0	SROUB / BOLT / SCHRAUBE	M4x8	6
7	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	2
8	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 4,3	6
9	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6,4	2
10	92.152.001	0	VENTIL SARTICI / CHOKE VALVE / DROSSELVENTIL	VS01-04/R 2.5-0	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.9. Doraz / Stop piece / Anschlag




NAZEV SESTAVY DORAZ	CÍSLO SESTAVY 201.0514-600	STROJ STG-250DGS
Konstruoval:		
Datum: 17. 08.2011		
Meritko: 1:2		

7.10. Kusovník / Piece list / Stückliste -
Doraz / Stop piece / Anschlag

Cislo Sestavy 201.0514-600		Ver. 0	Nazev sestavy DORAZ/STOP PIECE /ANSCHLAG		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.0514-601	2	DORAZ / STOP PIECE / ANSCHLAG	d 16	1
2	30.0703-013	0	TELESO DORAZU / STOP BODY / ANSCHLAGKÖRPER	ODLITEK	1
3	30.0703-016	1	PAKA / LEVER / HEBEL	d6	1
4	30.0703-010.A	1	TYC / POLE / STANGE	d 25	1
5	31.0304-013	0	PRUZINA / SPRING / FEDER	2.5x21.5x60x7	1
6	90.300.02.006	0	KOLIK VALC. KAL. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLIK 6x32	1
7	94.001.001	0	RUKOJET / HANDLE / GRIFF	M6 PRUMER 16	1
8	94.006.001	0	SROUB / BOLT / SCHRAUBE	M8x17	1

7.11. Podstavec / Base / Untersatz




NAZEV SESTAVY PODSTAVEC	CÍSLO SESTAVY 201-ER251-100	STROJ EGO 250DGS
Konstruoval: MUSIL		
Datum: 26. 06.2015		
Meritko: 13:100		

7.12. Kusovník / Piece list / Stückliste -
Podstavec / Base / Untersatz

Císlo Sestavy 201.ER251 - 100		Ver. 0	Název sestavy PODSTAVEC/BASE/UNTERSATZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0501-103	1	DRŽÁK / HOLDER / HALTER	P3x100	1
2	30.0513-205	1	VÍKO / COVER / DECKEL		1
3	30.0513-304	2	PANEL / PANEL / PANEL	P 2x311	1
4	30.ER251-002	0	PLECH / PLATE / BLECH	P 1x200	2
5	30.ER251-003		PLECH / PLATE / BLECH	P 1x200	2
6	30.ER251-101	0	PODSTAVEC / BASE / UNTERSATZ		1
7	30.ER251-108	0	KOSTKA / /	HR30x16	4
8	91.071.005	0	PRŮCHODKA / LEADTHROUGH / DURCHFÜHRUNG		1
9	91.071.015	0	VYVODKA / BUSHING / TÜLLE		1
10	91.071.022	0	VYVODKA / BUSHING / TÜLLE		1
11	91.072.016	0	MATICE / NUT / MUTTER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.13. Konzola otočná / Turnable consol / Drehkonsole



NAZEV SESTAVY KONZOLA OTOCNA	CISLO SESTAVY 201-ER252-100	STROJ ERG0250DGS
Konstruoval: MUSIL		
Datum: 05. 01. 2015		
Meritko: 33:100		


7.14. Kusovník / Piece list / Stückliste -
Konzola otočná / Turnable consol / Drehkonsole

Císlo Sestavy 201.ER252-100		Ver. 0	Název sestavy KONZOLA OTOČNÁ/TURNABLE CONSOL/DREHKONSOLE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.0704-100	0	KARTAC / BRUSH / BÜRSTE		1
2	30.0502-605	0	MÉRITKO / MEASURE / SKALA	P 0.5 x15	1
3	30.0514-603	0	DRŽAK / HOLDER / HALTER	P 5x20	1
4	30.0702-008	0	POUZDRO / SLEEVE / BÜCHSE	TR 70x5	1
5	30.0702-012	0	VÍKO / COVER / DECKEL	d 70	1
6	30.0702-013	0	SROUB / BOLT / SCHRAUBE	M8	1
7	30.ER252-101	0	KONZOLA OTOČNÁ / TURNABLE CONSOL / DREHKONSOLE		1
8	30.ER252-102	0	SEGMENT / SEGMENT / SEGMENT	P 8x105	1
9	30.ER252-103	0	SROUB / BOLT / SCHRAUBE	M12	1
10	30.ER252-114	0	KONZOLA / CONSOLE / KONSOLE		1
11	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x20	1
12	90.001.25.057	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x25	4
13	90.003.20.010	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x10	1
14	90.005.55.024	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x25	1
15	90.011.27.012	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8x16	3
16	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	1
17	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10	1
18	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		1
19	95.300.002	0	LOŽISKO KUŽELÍK / BEARING / LAGER	32008AX	2
20	96.001.018	0	TESNĚNÍ / SEALING / DICHTUNG		2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.15. Kartáč / Brush / Bürste


Cislo Sestavy 201.0704-100		Ver. 0	Název sestavy KARTAC/BRUSH/BÜRSTE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0104-022	0	DRŽÁK / HOLDER / HALTER	HR 16x16	1
2	30.0704-029	0	HRDEL / SHAFT / WELLE	d 14	1
3	31.0704-031	0	KARTAC / BRUSH / BÜRSTE		1
4	90.150.50.006	0	PODLOŽKA DIN125 / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 10,5	1
5	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	1
6	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6,4	1
7	95.800.001	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 6	1
8	90.001.25.019	0	SROUB IMBUS CERNENY / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x25	1



7.16. Válec zvedací / Lifting cylinder / Hebezyylinder

Schémata
Schemata
Schematische




NAZEV SESTAVY VALEC ZVEDACI	CISLO SESTAVY 201.ER257-010	STROJ ERG250
	Konstruoval: MUSIL	
	Datum: 22. 07.2015	
	Meritko: 1:2	

7.17. Kusovník / Piece list / Stückliste -
Válec zvedací / Lifting cylinder / Hebezyylinder

Císlo Sestavy 201.ER257-010		Ver. 0	Nazev sestavy VALEC ZVEDACI/LIFTING CYLINDER/HEBEZYLINDER		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozmer	Ks
1	30.0507-904	0	VÍKO / COVER / DECKEL	d 40	1
2	30.LC07-106	0	PIST / PISTON / KOLBEN	ODLITEK	1
3	30.ER257-012	0	VALEC / ROLLER / ZYLINDER	TRUBKA 45/40	1
4	30.ER257-011	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d 1618	1
5	30.0507-003	0	VÍKO / COVER / DECKEL	d 45	1
6	30.0507-004	1	KLAPKA / PULLEY / VENTILKLAPPE	P 4x37	1
7	90.151.50.004		PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 6	1
8	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	1
9	96.001.010	0	KROUZEK O STATICKY / STATIC O RING / O-RING STATISCH	d36x2	1
10	95.801.005	0	SEGR DIRA / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNY KROUZEK 40	4
11	96.002.017	0	KROUZEK O STATICKY / STATIC O RING / O-RING STATISCH	d34x3	1
12	96.041.001	0	TESNENÍ / SEALING / DICHTUNG	d16	1
13	96.060.001	0	KROUZEK STIRACÍ / SCRAPER RING / ABSTREIFRING	16x22 NBR 70	1
14	96.002.017	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	34x3 NBR 70SH	1
15	31.0707-014	0	PRUŽINA / SPRING / FEDER	0.63x10x20x9.5	1
16	30.0507-913	2	POUZDRO / SLEEVE / BÜCHSE	d 16	1
17	90.150.50.007	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 13	1
18	90.001.25.057	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x25	1
19	92.002.001	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4"	1
20	31.0507-010	0	VÍKO / COVER / DECKEL		1
21	30.LC07-002	1	DRŽAK / HOLDER / HALTER	HR 30x30	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.18. Stůl / Table / Tisch



NAZEV SESTAVY STŮL	CÍSLO SESTAVY 201.ER259-100	STROJ ERG0250DGS
Konstruoval: MUSIL		
Datum: 26. 02.2016		
Měřitko: 1:4		

7.19. Kusovník / Piece list / Stückliste - Stůl / Table / Tisch

Císlo Sestavy 201.ER259-100		Ver. 1	Název sestavy STUL/TABLE/TISCH		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.ER253-210 (1)	0	SVERAK / VICE / SCHRAUBSTOCK		1
2	201.ER259-110	0	DORAZ / STOP PIECE / ANSCHLAG		1
3	30.0509-606	0	VALECEK / CYLINDER / ROLLE	d15	1
4	30.ER259-101	0	STUL / TABLE / TISCH		1
5	30.ER259-102	0	TYC / POLE / STANGE	d10	1
6	30.ER259-103	0	UKAZATEL / INDICATOR / ZEIGER	P 1x15	1
7	30.ER259-114	0	CELIST / JAW / BÄCKE	ODLITEK	1
8	30.ER259-115	0	CELIST / JAW / BÄCKE	ODLITEK	1
9	90.001.25.015	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X10	4
10	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X35	2
11	90.001.25.061	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X45	2
12	90.001.25.063	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X60	2
13	90.001.25.065	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X80	2
14	90.001.25.066	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X120	2
15	90.003.20.004	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6X10	1
16	90.100.55.007	0	MATICE / NUT / MUTTER	MATICE - M12	2
17	90.150.50.004	0	PODLOZKA / WASHER / UNTERLEGSCHLEIBE	PODLOZKA 6,4	2
18	90.151.50.002	0	PODLOZKA / WASHER / UNTERLEGSCHLEIBE	PODLOZKA 12	1
19	94.008.009	0	PAKA UPIŇACÍ / ATTACHMENT LEVER / SPANNHEBEL	M12	1
20	95.014.008	0	LOŽISKO / BEARING / LAGER	7206	1
21	95.691.006	0	KOLEČKO / WHEEL ROLLE	RB 8	25

I. ZRUSEN SVERAK 201.ER253-110 A NAHRAZEN 201.ER253-210. 046/ZM053 26.2.2016 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.21. Kusovník / Piece list / Stückliste -
Svěrák / Vice / Schraubstock


Císlo Sestavy 201.ER253-210		Ver. 0	Název sestavy SVERAK/VICE/SCHRAUBSTOCK		
Poz	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.ER253-013	0	TYC / POLE / STANGE	d 12	1
2	30.ER253-014	0	EXCENTR / CAM / EXCENTER	d 25	1
3	30.ER253-015	0	CEP / LUG / BOLZEN	D 30	1
4	30.ER253-217	0	KLIN / WEDGE / KEIL	HR 15x10	1
5	30.ER253-019	0	POUZORO / SLEEVE / BUCHSE	d40	1
6	30.ER253-021	0	CEP / LUG / BOLZEN		1
7	30.ER253-116	0	DESKA / BOARD / PLATTE	HR 200x10	1
8	30.ER253-211	0	TELESO SVERAKU / VICE BODY / SCHRAUBSTOCKKÖRPER		1
9	30.ER253-212	0	CELIST POHYBLIVÁ / MOVING JAW / BEWEGLICHE BACKE		1
10	31.ER253-018	0	SROUB / BOLT / SCHRAUBE	TR 24x5 R	1
11	31.M203-012	0	PRUŽINA / SPRING / FEDER	d 1,5	1
12	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	2
13	90.001.25.019	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x25	3
14	90.002.20.005	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5x10	1
15	90.004.20.014	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x10	1
16	90.303.07.008	0	KOLIK PRUŽNY / PIN / BOLZEN	KOLIK 5x20	1
17	94.008.003	0	PAKA UPINACÍ / ATTACHMENT LEVER / SPANNHEBEL	M8x40	1
18	94.010.002	0	RUKOJET / HANDLE / GRIFF		1
19	94.010.004	0	KOLO / WHEEL / UMLENKRAD	d 100/14H7	1
20	94.102.024	0	RUKOJET / HANDLE / GRIFF	465367	2
21	95.700.002	0	POUZORO / SLEEVE / BUCHSE	14x15	1
22	95.800.004	0	SEGR HRDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUŽEK 12	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.22. Doraz / Stop piece / Anschlag

Schémata
Schemata
Schematics



NAZEV SESTAVY DORAZ	CISLO SESTAVY 201.ER259-110	STROJ
	Konstruoval: MUSIL	
	Datum: 05. 01. 2015	
	Meritko: 1:1	


7.23. Kusovník / Piece list / Stückliste - Doraz / Stop piece / Anschlag

Císlo Sestavy 201.ER259-110		Ver. 0	Název sestavy DORAZ/STOP PIECE/ANSCHLAG		
Poz.	Objednací číslo	Ver.	Název položky	Rozmer	Ks
1	30.ER259-111	0	DRZAK / HOLDER / HALTER		1
2	30.ER259-112	0	DRZAK / HOLDER / HALTER		1
3	30.ER259-113	0	TYC DORAZU / STOP POLE / ANSCHLAGSTANGE		1
4	31.K303-021	0	PRUŽINA / SPRING / FEDER	2.0x16x53x13.5	1
5	90.005.55.015	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x20	1
6	90.005.55.XXX	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x10	1
7	90.011.27.004	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x10	4
8	90.015.25.013	0	SROUB IMBUS / /	M10	2
9	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
10	90.163.00.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	NORD-LOCK	2
11	95.001.004	0	LOŽISKO / BEARING / LAGER	6000 2RS	1
12	95.800.003	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 10	1
13	95.800.004	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 12	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.24. Rameno / Saw arm / Sägerahmen

Schémata
Schemata
Schematische




NAZEV ŠESTAVY RAMENO	CÍSLO ŠESTAVY 201.ER274-000	STROJ ERG275
Konstruoval: MUSIL		
Datum: 13. 04. 2016		
Meritko: 17:100		

7.25. Kusovník / Piece list / Stückliste -
Rameno / Saw arm / Sägerahmen

Cislo sestavy 201.ER274-000		Ver. I	Název sestavy RAMENO/SAW ARM/SÄGERAHMEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.ER235-010	I	POHON / DRIVE / ANTRIEB		I
2	201.ER235-020	0	POHON / DRIVE / ANTRIEB		I
3	201.ER276-000	0	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		I
4	201.ER278-000	0	NAPINÁNÍ / TENSIONING / SPANNUNG		I
5	30.0704-041 (1)	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1.5x56	I
6	30.0704-043 (1)	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1.5x46	I
7	30.1814-011	2	DRŽÁK / HOLDER / HALTER	P 3x76	2
8	30.ER234-002	0	VÍKO / COVER / DECKEL		I
9	30.ER234-008	0	PANT / HINGE / TÜRBAND	P 2x36	2
10	30.ER254-003	0	CEP / LUG / BOLZEN	d 30	I
11	30.ER254-008	I	DRŽÁK / HOLDER / HALTER	P 4x60	I
12	30.ER254-009	I	TYC / POLE / STANGE	d 30	I
13	30.ER254-011	I	CEP / LUG / BOLZEN	7h9	2
14	30.ER274-001	I	RAMENO / SAW ARM / SÄGERAHMEN		I
15	30.ER274-004	0	KRYT RAMENE / SHOULDER COVER / RAHMENABDECKUNG	P 1.5x61	I
16	30.ER274-005	0	KRYT RAMENE / SHOULDER COVER / RAHMENABDECKUNG		I
17	30.ER274-007	0	KRYT NAPINÁNÍ / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 6x80	I
18	30.ER274-010 (1)	0	PAS PÍLOVÝ / SAW BELT / SÄGEBAND	3125x25(7)x0.9	I
19	30.ER275-001	0	KOLO HNACÍ / DRIVE WHEEL / ANTRIEBSRAD		I
20	90.001.25.044	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x14	I
21	90.012.50.007 (1)	0	SROUB / ROLLER BOLT / ZYLINDERSCHRAUBE	SROUB M4x30	2
22	90.013.27.003	0	SROUB / BOLT / SCHRAUBE	M5x10	4
23	90.013.27.007 (1)	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M6x10	6
24	90.013.27.011 (1)	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M8x12	I
25	90.013.27.017 (1)	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M4x6	2
26	90.150.50.002 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 4,3	2
27	90.150.50.007	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 13	2
28	90.151.50.001	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 10	I
29	90.400.52.001	0	ZATKA / PLUG / STOPFEN	M10x1	I
30	90.400.52.002	0	ZATKA / PLUG / STOPFEN	M16x1.5	I
31	91.001.217	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	90L-B14	I
32	91.070.011	0	VÝVODKA / BUSHING / TÜLLE	M16x1.5	I
33	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER	-RIWK	I
34	91.173.012	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		I

Cislo sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.26. Rameno / Saw arm / Sägerahmen



NAZEV SESTAVY RAMENO	CISLO SESTAVY 201.ER274-000	STROJ ERG275
Konstruoval: MUSIL		
Datum: 13. 04. 2016		
Meritko: 17:100		

7.27. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen

35	94.201.003	0	REDUCE / REDUCTION / ADAPTOR / REDUKTION	YRS 6-8-6	1
36	94.202.002	0	REDUCE / REDUCTION / ADAPTOR / REDUKTION	GES 6/R1/4"	4
37	95.800.016	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNY KROUZEK 42	2
38	95.802.003	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 5	4
39	96.081.001	0	KROUZEK TESNICI / SEAL RING / DICHTRING	23x15x3	1
40	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	2

I.ZRUS.KRYT PASU 44.103.003 A NAHR.30.ER274-010,PRID.KRYT PASU 30.0704-041,30.0704-043,2xSROUB M4x6(90.012.27.017)
1xSROUB M8x12(90.013.27.011),6xSROUB M6x10(90.013.27.007),2xPODLOZKA 4,3(90.150.50.002),2xSROUB M4x30(90.012.50.007).
044/ZM093 13.4.2016 SLEZACKOVA


Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.28. Pohon / Drive / Antrieb

Císlo Sestavy 201.ER235-010		Ver. 2	Název sestavy POHON/DRIVE /ANTRIEB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0508-002 (2)	0	PODLOŽKA / WASHER / UNTERLESCHEIBE	d 40	1
2	30.ER235-011	0	KOLO OZUBENÉ / COG WHEEL / ZAHNRAD		1
3	30.ER235-012	0	KROUZEK / RING / RING	Tr 45x5	1
4	30.ER235-013	0	KROUZEK / RING / RING	Tr 80x5	1
5	30.ER235-014	0	VÍKO / COVER / DECKEL	TR 82,5x12,5	1
6	30.ER235-015	1	KROUZEK / RING / RING	D 50	1
7	90.011.27.008	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10x20	1
8	95.001.026	0	LOŽISKO / BEARING / LAGER	6307 2RS	1
9	95.201.010	0	LOŽISKO / BEARING / LAGER	VALEČKOVÁ L. IRADA	1
10	95.800.014 (1)	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 35	1
11	95.801.013	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 80	2
12	95.810.009	0	PERO TESNÉ / TIGHT SPRING / PASSEFEDER	PERO 10x8x30	1
13	95.830.059	0	GUFERO / GIT SEAL / DICHTUNG	GUFERO 50x65x8	1
14	96.002.030	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	74x3	1
15	96.002.047	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	35x2,5	1

1. PRIDAK KROUZEK 95.800.014 026/ZM081 24.3.2016 SLEZACKOVA

2. ZRUS. PODLOŽKA 30.7901-018 A NAHR. 30.0508-002. 044/ZM093 14.4.2016 SLEZACKOVA




Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název polozky/Volume title/Name der Position; Rozměr/Stock size/Abmessung



7.29. Pohon / Drive / Antrieb

Schémata
Schemata
Schematische

Číslo Sestavy 201.ER235-020		Ver.	Název sestavy POHON/DRIVE / ANTRIEB	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr
1	30.ER235-021	0	KOLO OZUBENÉ / COG WHEEL / ZAHNRAD	1
2	95.001.029	0	LOŽISKO / BEARING / LAGER	6003 2RS
				2



7.30. Vedení pásu / Belt guide / Sägebandführung



NAZEV SESTAVY VEDENÍ PASU	ČÍSLO SESTAVY 201-ER276-000	STROJ ERG275
Konstruoval: MUSIL		
Datum: 13. 01. 2015		
Měřítko: 1:2		

7.31. Kusovník / Piece list / Stückliste - Vedení pásu / Belt guide / Sägebandführung

Schéματα
Schemata
Schematische


Císlo sestavy 201.ER276-000		Ver. 0	Název sestavy VEDENÍ PASU/BELT GUIDE / SÄGEBANDFÜHRUNG			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks	
1	201.0510-600	1	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	SESTAVA	1	
2	201.0510-500	1	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	SESTAVA	1	
3	30.ER236-002	0	LISTA / TRIM / LEISTE	HR 40x15	1	
4	30.0104-015	5	LISTA / TRIM / LEISTE	HR 40x20	1	
5	30.ER276-003	0	UPÍNKA / FASTENER / SPANNEISEN	P 8x40	1	
6	94.008.005	0	KLIČKA / HANDLE / KURBEL	M10	1	
7	30.ER276-007	0	PODLOŽKA DISTANČNÍ / SPACER WASHER / DISTANZSCHEIBE	P 3x35	2	
8	90.163.00.001	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	NORD-LOCK	4	
9	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	4	
10	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x30	1	
11	30.ER256-005	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1,5x94	1	
12	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 5,3	2	
13	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	2	

Císlo sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position);
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.32. Kostka vodící / Lead cube / Führungsklotz

Cislo Sestavy 201.0510-500		Ver. I	Nazev sestavy KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozměr	Ks
1	30.LK10-006	1	TRUBKA / TUBE / ROHR	TR 12x2	1
2	30.LK10-008	2	TRUBKA / TUBE / ROHR	TR 8x1	1
3	30.LK10-109	0	PRÍLOŽKA / STRAP / LASCHE	P 2-10	1
4	31.LK10-007	0	TVRDOKOV / HARD METAL / HW-SEGMENT	HR 18.1x15.5	2
5	85.LK10-201	0	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	ODLITEK	1
6	90.001.25.007	0	SROUB IMBUS ČERNÝ / /	M5x10	1
7	90.001.25.009	0	SROUB IMBUS ČERNÝ / /	M5x16	2
8	90.005.55.018	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x35	1
9	90.013.27.001	0	SROUB / BOLT / SCHRAUBE	M4x8	2
10	90.015.25.033 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x45	1
11	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	2
12	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 4,3	2
13	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 5,3	2
14	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8,4	1
15	95.001.001	0	LOŽISKO / BEARING / LAGER	608 2RS	2
16	99.040.002	0	TVRDOKOV / HARD METAL / HW-SEGMENT	d 12	1

I. ZRUS. SROUB M8x45 6HRANNÝ (90.005.55.020) A NAHR. M8x45 DIN7984 (90.015.25.033). 286/ZM342 5.12.2012




7.33. Kostka vodící / Lead cube / Führungsklotz

Schéματα
Schemata
Schematische


Cislo Sestavy 201.0510-600		Ver. 1	Název sestavy KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.LK10-006	1	TRUBKA / TUBE / ROHR	TR 12x2	1
2	30.LK10-008	2	TRUBKA / TUBE / ROHR	TR 8x1	1
3	30.LK10-109	0	PŘILOŽKA / STRAP / LASCHE	P 2-10	1
4	31.LK10-007	0	TVRDOKOV / HARD METAL / HW-SEGMENT	HR 18.1x15.5	2
5	85.LK10-201	0	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	ODLITEK	1
6	90.001.25.007	0	SROUB IMBUS ČERNÝ / /	M5x10	1
7	90.001.25.009	0	SROUB IMBUS ČERNÝ / /	M5x16	2
8	90.005.55.018	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x35	1
9	90.013.27.001	0	SROUB / BOLT / SCHRAUBE	M4x8	2
10	90.015.25.033 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x45	1
11	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	2
12	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 4.3	2
13	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 5.3	2
14	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8.4	1
15	95.001.001	0	LOŽISKO / BEARING / LAGER	608 2RS	2
16	99.040.002	0	TVRDOKOV / HARD METAL / HW-SEGMENT	d 12	1

1.7RUS.SROUB M8x45 6HRANNÝ(90.005.55.020) A NAHR.M8x45 DIN7984(90.015.25.033). 286/ZM342 5.12.2012




A - A
67:100

OKOLI TVRDOKOVU
PO OBYVODU 3x
ROZTEMOVAT
DULCIKEM



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.34. Napínání / Tensioning / Spannung



NAZEV SOUSTAVY NAPÍNÁNÍ	ČÍSLO SOUSTAVY 201.ER278-000	STŘEŠÍ ERG275
Konstruoval: MUSIL		
Datum: 15. 01. 2015		
Měřítko: 1:2		

7.35. Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung

Schémata
Schemata
Schematische

Císlo Sestavy 201.ER278-000		Ver. 0	Název sestavy NAPÍNÁNÍ / TENSIONING / SPANNUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0708-102	0	CEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		1
2	95.800.012	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 25	1
3	95.001.018	0	LOŽISKO / BEARING / LAGER	6205 2RS	2
4	95.801.009	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 52	1
5	30.0702-023	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	P 2x40	1
6	30.0505-011	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	TYC 40	1
7	90.005.55.023	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x20	1
8	30.ER278-011	0	VEDENÍ / GUIDE / BACKENFÜHRUNG		1
9	90.300.02.012	0	KOLÍK VALC. KAL. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLÍK 8x50	1
10	30.ER258-004	0	DRŽÁK / HOLDER / HALTER		1
11	90.350.02.002	0	PRŮŽINA TALÍROVÁ / DISC SPRING / TELLERFEDER	35,5x18,3x2,0x2,8	11
12	30.ER258-005	0	PRÍLOŽKA / STRAP / LASCHE	P 4x42	1
13	95.750.001	0	KROUZEK KU / KU RING / KU-RING	16x1	2
14	31.0104-006	0	HVEZDICE / STAR WHEEL / STERN	PLAST	1
15	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
16	90.005.55.017	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x30	1
17	90.004.20.007	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x10	1
18	30.ER258-006	0	TAHLO / GUY ROD / ZUGSTANGE	M6	1
19	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE _ M6	2
20	30.ER258-008	0	TRUBKA / TUBE / ROHR	TR 12x2	1
21	30.ER258-007	0	STUPNICE / SCALE / SKALA	P 1x41	1
22	30.ER278-001	0	KOLO NAPÍNACÍ / TENSIONING WHEEL / UMLENKRAD		1
23	90.012.50.019	0	SR. S VALC. HLAV. / ROLLER BOLT / ZYLINDERSCHRAUBE	SROUB M3x6	1
24	94.001.005	0	RUKOJET / HANDLE / GRIFF	M16	1
25	90.001.25.028	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x10	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung